

1281/5

**Sewing unit for closing seams
for trousers and skirts**

Operating instructions

Installation instructions

Service instructions

1

2

3



Foreword

This instruction manual is intended to help the user to become familiar with the machine and take advantage of its application possibilities in accordance with the recommendations.

The instruction manual contains important information on how to operate the machine securely, properly and economically. Observation of the instructions eliminates danger, reduces costs for repair and down-times, and increases the reliability and life of the machine.

The instruction manual is intended to complement existing national accident prevention and environment protection regulations.

The instruction manual must always be available at the machine/sewing unit.

The instruction manual must be read and applied by any person that is authorized to work on the machine/sewing unit. This means:

- Operation, including equipping, troubleshooting during the work cycle, removing of fabric waste,
- Service (maintenance, inspection, repair and/or
- Transport.

The user also has to assure that only authorized personnel work on the machine.

The user is obliged to check the machine at least once per shift for apparent damages and to immediately report any changes (including the performance in service), which impair the safety.

The user company must ensure that the machine is only operated in perfect working order.

Never remove or disable any safety devices.

If safety devices need to be removed for equipping, repairing or maintaining, the safety devices must be remounted directly after completion of the maintenance and repair work.

Unauthorized modification of the machine rules out liability of the manufacturer for damage resulting from this.

Observe all safety and danger recommendations on the machine/unit! The yellow-and-black striped surfaces designate permanent danger areas, eg danger of squashing, cutting, shearing or collision.

Besides the recommendations in this instruction manual also observe the general safety and accident prevention regulations!

General safety instructions

The non-observance of the following safety instructions can cause bodily injuries or damages to the machine.

1. The machine must only be commissioned in full knowledge of the instruction book and operated by persons with appropriate training.
2. Before putting into service also read the safety rules and instructions of the motor supplier.
3. The machine must be used only for the purpose intended. Use of the machine without the safety devices is not permitted. Observe all the relevant safety regulations.
4. When gauge parts are exchanged (e.g. needle, presser foot, needle plate, feed dog and bobbin) when threading, when the workplace is left, and during service work, the machine must be disconnected from the mains by switching off the master switch or disconnecting the mains plug.
5. Daily servicing work must be carried out only by appropriately trained persons.
6. Repairs, conversion and special maintenance work must only be carried out by technicians or persons with appropriate training.
7. For service or repair work on pneumatic systems, disconnect the machine from the compressed air supply system (max. 7-10 bar). Before disconnecting, reduce the pressure of the maintenance unit.
Exceptions to this are only adjustments and functions checks made by appropriately trained technicians.
8. Work on the electrical equipment must be carried out only by electricians or appropriately trained persons.
9. Work on parts and systems under electric current is not permitted, except as specified in regulations DIN VDE 0105.
10. Conversion or changes to the machine must be authorized by us and made only in adherence to all safety regulations.
11. For repairs, only replacement parts approved by us must be used.
12. Commissioning of the sewing head is prohibited until such time as the entire sewing unit is found to comply with EC directives.



It is absolutely necessary to respect
the safety instructions marked by these signs.
Danger of bodily injuries !
Please note also the general safety instructions.



Preface and general safety instructions

Part 1: Operating instructions cl. 1281/5

1.	Description of product	
1.1	Description of proper use	2
1.2	Brief description	2
1.3	Technical data	3
2.	Optional equipment	4
3.	Switching on - Switching off - Program stop	
3.1	Switching on	5
3.2	Switching off	5
3.3	Program stop	6
3.4	Restart after program stop	6
4.	Operation of the sewing machine head	
4.1	General notes	7
4.2	Recommended threads	8
4.3	Removing/ Putting on the fabric sliding sheet	9
5.	Operation of the sewing unit	
5.1	Preparation table and worktable	10
5.2	Mouse with guide rail and return mechanism	11
5.3	Feeding the workpieces and starting the sewing process	13
5.4	Adjusting the blowing air for the nozzles in the table top	14
5.5	Setting the return speed of the mouse	15
5.6	Adjusting the fullness of needle and bottom feed	16
5.7	Setting the pressure of the puller.	17
5.8	Stacker	18
6.	Operation of the control	
6.1	Operator terminal	19
6.2	User interface	21
6.2.1	Menu structure of the sewing and setting programs.	21
6.3	Seam program.	23
6.4	Adjusting the control	25
6.4.1	Altering seam-specific parameters.	26
6.4.2	Altering global parameters	32
6.4.3	Input - Output test.	33
6.4.4	Creation of seam programs	35
6.4.5	Deleting a seam program	36
6.4.6	Altering seam programs (Changing/Completing the sequence)	36

7.	Error messages	37
8.	USB stick	
8.1	General notes	38
8.2	Formatting of the USB stick	38
8.3	Plugging the USB stick in the control	38
8.4	USB functions	39
8.4.1	Storing data on the USB stick.	41
8.4.2	Loading data from the USB stick	41
8.4.3	Data comparison	42
8.4.4	Deleting data from the USB stick.	43
8.4.5	Loading software version from the USB stick	44
8.5	Removing the USB stick	45
9.	Maintenance	
9.1	Cleaning and checking	46
9.2	Oil lubrication	48

1. Description of product

1.1 Description of proper use

The **1281/5** is a sewing unit which can properly be used for sewing light to medium-weight material. Such material is, as a rule, made of textile fibres. These materials are used in the garment industry.

In general only dry material must be sewn on this machine. The material must not contain any hard objects.

The seam is generally made with core thread, polyester fibre or cotton threads.

The dimensions for needle and hook threads can be taken from the table in chapter 4.2.

Before using any other threads it is necessary to estimate the consequential dangers and to take the respective safety measures, if required.

This sewing unit must only be installed and operated in dry and well-kept rooms. If the sewing unit is used in other rooms, which are not dry and well-kept, further measures to be agreed upon may become necessary (see EN 60204-31 : 1999).

We, as a manufacturer of industrial sewing machines, assume that at least semi-skilled operating personnel will be working on our products so that all usual operations and, where applicable, their risks are presumed to be known.

1

1.2 Brief description

The **Beisler 1281/5** is a sewing unit for closing long seams, as e.g.

- trousers side seams and crotch seams,
- side seams without vent in upper fabric and lining in skirt parts.

According to the machine head it is possible to sew

- double-chainstitch seams (401),
- 4-thread safety seams (515) or 5-thread safety seams (516).

All sewing station components are mounted on a stand welded of square steel tubes and controlled by a microprocessor system.

The sewing station is operated via a control panel. Here it is possible to call up various control programs, to define new programs and to check all inlets and outlets for maintenance and repair purposes.

Machine head

- Pegasus overlock machine
EXT 3216-03
- Direct drive Efka Type DC 1500 /AB 221
- Microprocessor control, freely programmable
- Light barrier for recognizing the seam beginning and seam end for the automatic sewing start and stop
- Programmable edge guide for different material thicknesses, moving cross-line

Dimensions: 2300 x 1300 x 1500 mm (L x W x H)

Working height: 850...1200 mm
(upper table top edge)

Weight: 125 kg

Noise level: **LC = 81dB (A)**

Workstation-specific emission value according to DIN 45635-48-B-1

Stitch length: 2.6 mm

Seam length: 1000 mm

Speed: 6500 r/min

Material G1 DIN 23328: 2 layers

Measuring point according to
DIN 4895 Part 1 X = 550 mm Y = 350 mm Z = 600 mm

x - axis = at right angles to the feeding direction

y - axis = main feeding direction

z - axis = height

2. Optional equipment

See annex

3. Switching on - Switching off - Program stop



1


3.1 Switching on

- Switch on main switch 1 (turn in clockwise direction).
The control loads the machine program.
The basic display appears in the display of the control panel.

3.2 Switching off

- Switch off main switch 1 (turn counter-clockwise).

3.3 Program stop



2

2

1

1

For an immediate stop in case of operating errors, needle breakage etc. the safety system of the 1281/5 provides the following measures:

- Press program stop switch 2 at the control panel.
The running operations are stopped immediately.
- Turn main switch 1 counter-clockwise.
The sewing unit drops out immediately;
all movements of the sewing unit stop immediately.

3.4 Restart after program stop




Caution: Risk of injury!

Switch the main switch off.
Clear the fault only with the sewing unit switched off.
Only restart the sewing unit after the fault has been cleared.

- Switch on main switch 1 (turn in clockwise direction).
- Unlock the program stop switch.
The control loads the machine program.
The basic display appears in the display of the control panel.
The sewing unit is ready for operation again.

4. Operation of the sewing machine head

4.1 General notes



The operation of the sewing machine head (needle insertion, threading of needle thread and hook thread etc.) is described in the attached separate Pegasus operating instructions.

The instruction manual is included in the accessories of the sewing unit.



Attention: Risk of injury!

Please read the operating instructions of the sewing machine head carefully and observe all notes on safety.

4.2 Recommended threads

Needle system:	B27
Recommended needle size:	Nm 80 for very thin material Nm 90 for thin material Nm 100 for medium-weight material

High sewing security and good sewability are achieved with the following core threads:

- Two-ply polyester endless polyester core-spun (e.g. Epic Poly-Poly, Rasant x, Saba C, ...)
- Two-ply polyester endless cotton core-spun (e.g. Frikka, Koban, Rasant, ...)

If these threads are not available, the polyester fibre or cotton threads listed in the table can also be sewn.

Often two-ply core threads are offered by the thread manufacturers with the same designation as three-ply polyester fibre threads (3cyl.-spun). This causes uncertainty with regard to twisting and thread thickness.

When in doubt, unravel the thread and check whether it is twisted 2- or 3-ply.


The label no. 120 on the thread reel of a core thread corresponds e.g. to the thread size Nm 80/2 (see table values in brackets).

In case of monofilament threads you can use needle threads and hook threads of the same thickness. The best results are achieved with soft and elastic threads (software) of the thread thickness 130 Denier.

Recommended thread thicknesses:


Needle size Nm	Core thread		Core thread	
	Needle thread Polyester endless Label No.	Hook thread Polyester core-spun Label No.	Needle thread Polyester endless Label No.	Hook thread Cotton core-spun Label No.
80				
90	120 (Nm 80/2)	120 (Nm 80/2)	120 (Nm 80/2)	120 (Nm 80/2)
100	100 (Nm 65/2)	100 (Nm 65/2)	100 (Nm 65/2)	100 (Nm 65/2)
Needle size Nm	Polyester fibre thread (3cyl.-spun)		Cotton thread	
	Needle thread	Hook thread	Needle thread	Hook thread
80	Nm 120/3	Nm 120/3	Ne _B 60/3-80/3	Ne _B 60/3-80/3
90	Nm 80/3-120/3	Nm 80/3-120/3	Ne _B 50/3-70/3	Ne _B 50/3-70/3
100	Nm 70/3-100/3	Nm 70/3-100/3	Ne _B 40/3-60/3	Ne _B 40/3-60/3

4.3 Removing / Putting on the fabric sliding sheet



2

3



2

1

The fabric sliding sheet 2 is held in the gap of the table top by the magnets 1.
The edge guide 3 is fastened on the fabric sliding sheet.

Removing the fabric sliding sheet


- Carefully remove the edge guide 3 from the magnets in upward direction.
- Swivel the fabric sliding sheet aside.
The lower section of the sewing machine head is accessible now.

Putting on the fabric sliding sheet

- Push the fabric sliding sheet into the gap of the table top and insert in downward direction.

5. Operation of the sewing unit


5.1 Preparation table and worktable




The sewing unit is equipped with two preparation tables 1 and 2. The skirt parts or trousers parts are positioned on them.

On the worktable 4 the trousers parts or skirt parts are fed and clamped with the mouse 3.

5.2 Mouse with guide rail and return mechanism



3 2 1



7 6 5 4

The mouse is used for clamping the trousers and skirt parts to avoid their sliding away.

The guide rail 3 is flexible and adaptable to the contour of the workpiece.



Caution: Risk of injury !

Do not reach into the open mouse.

Inserting the workpiece

- Place the workpiece between mouse plate 2 and clamping arm 1.
- Close the mouse.


During the sewing process the mouse is drawn along the guide rail 3 until the opening of the clamping arm 1 is released by a limit switch.

Then the mouse is pulled back by the return mechanism 4 until the adjustable stop 5 is touched.



9

3



9


8

Aligning the guide rail 3

- Place the workpiece 8 on the worktable opposite to the sewing direction.
- Loosen toggle screws 9.
- Place the guide rail 3 close to the contour of the workpiece.
- Tighten toggle screws 9 again.

1

Opening the mouse manually



10


- Actuate lever 10. The mouse opens.

5.3 Feeding the workpieces and starting the sewing process


The sewing unit for closing seams 1281/5 works semi-automatically at high speed.

The operator of the sewing unit has to do the following:

- ✱ call up the desired seam program;
- ✱ feed and align the workpiece precisely;
- ✱ sew the first seam section manually;
- ✱ start the automatic sewing process;
- ✱ supervise the sewing process of the unit;
- ✱ remove the finished parts from the stacker.



2 1




6 5 4 3

Feeding the workpieces and starting the sewing process

- 1) Select the seam program at the control panel.
- 2) Place the workpieces 2 on the worktable and align them.
- 3) Position the workpieces in the mouse 1.
- 4) Close the mouse.
- 5) Push both workpieces under the sewing foot 6 and directly in front of the needle.
- 6) Step the foot pedal forward and sew over the pocket and the hip bow manually.
- 7) Separate the trousers or skirt parts with three fingers. Hold one finger under, one between and one above the workpieces.
- 8) Step the foot switch back. The contour guide moves between the parts. The feeding puller lowers.
- 9) Step the foot pedal forward. The automatic sewing process starts.
- 10) The finished workpieces are stacked.
- 11) The mouse returns to the feeding position.

5.4 Adjusting the blowing air for the nozzles in the table top



1





2

The blowing nozzles 1 in the table top support the precise stacking of the workpieces.

- Set the intensity of the air blast by dial 2 at the control panel.
Turn the dial to the right = increase the intensity of air blast
Turn the dial to the left = reduce the intensity of air blast

1

5.5 Setting the return speed of the mouse



The cylinder 2 presses the mouse mechanics 1 down. Thus, the mouse is pulled back to the feeding position.

The return speed can be set.

- Set the speed by dial 3 at the control panel.
 - Turn dial to the right = higher speed
 - Turn dial to the left = less speed

5.6 Adjusting the fullness of needle and bottom feed

Operator terminal in case of fullness adjustment via cylinder



1

Operator terminal in case of fullness via step motors (optional equipment)



2

1

1

Needle feed, bottom feed and puller feed can be adapted to the sewing conditions with the dials 1 and 2.

Via the control parameters you can determine which feed is changed with the dial 2.


Adjusting the puller feed

- Set the dial 1 correspondingly.
Setting range: + 0 to 6 right
– 0 to 6 left

Adjusting the needle and bottom feed

- Make the corresponding settings in the control in the menu “Seam-specific parameters”.
- Set the dial 2 correspondingly.
Setting range: + 0 to 6 right
– 0 to 6 left

5.7 Setting the pressure of the puller



The pressure of the puller rollers 1 can be influenced via turning knob 2.

- Turn knob 2 to the right.
The pressure is increased.
- Turn knob 2 to the left.
The pressure is reduced.

5.8 Stacker



The finished workpieces are stacked on the throw-over stacker 2.
The stacked and clamped workpieces can be removed by actuating the foot switch 1.
The stacker is accessed by a control pulse. The pneumatic functions can be taken from the pneumatic wiring diagram.



Caution: Risk of injury!

Do not reach into the working area of the throw-over stacker during the stacking operation.

Manual stacking

- Press key 3 at the control panel.
A stacking process is carried out.

Removing stacked parts

- Actuate foot switch 1 and keep it actuated.
- Remove the stacked parts.

6. Operation of the control

6.1 Operator terminal

For the input and output of data an operator terminal with an LCD display and function keys is used.




Key Function


1	0	Seam program 1 to program 99
	7	Sewing stop within the seam
	F1	Move the contour guide back to the basic position
	F2	Manual stacking
	P	Menu selection/ Store data
P	1	Needle feed, seam lines and quantities adjustable
P	2	Differential feed, seam lines and quantities adjustable
P	3	Adjust the ejector roller
P	4	Adjust the puller
P	5	Set the machine parameters
P	6	Switch the potentiometer on / off in the individual lines (optional equipment)
P	7	Adjust seam line
P	8	Input-/ Output test

Key		Function
P	9	Program the sequence (S) Creation of programs (Prg)
P	0	Setting the global parameters
	E	Enter key
F1	F2	Select parameter / scroll
-	+	Alter parameter values

6.2 User interface

6.2.1 Menu structure of the sewing and setting programs





Calling up sewing programs

- Switch the main switch on.
The control initializes.
The seam program previously used is loaded.
- Press one of the keys “1, 2, 3, 4, 5, 6, 7, 8, 9, 0”.
The selected seam program is loaded.

1

Calling up the parameter menu

- Switch the main switch on.
The control initializes.
The previously used program appears in the display.
- Press key “P”.
The selection menu is called up.
- Press one of the keys “1, 2, 3, 4, 5, 6, 7, 8, 9, 0”.
The display changes over to the corresponding function.

Mouse back

When the seam program is selected:


- Press key “F1”.
The mouse returns to its basic position.

Manual stacking

When the seam program is selected:

- Press key “F2”.
The stacker makes a stacking movement.

6.3 Seam programs



Designation of the individual seams:

4 = Crotch seam of hind trousers on top/ lining down

6 = Crotch seam of hind trousers down/ lining on top

5 = Side seam of hind trousers down/ lining on top

7 = Side seam of hind trousers on top/ lining down


A seam program in the display of the control panel



Program No.

Seam No.

The sewing unit 1281/5 is delivered with 9 standard seam programs:



1

Program No.	Seam No.	Operation	Position of trousers	Notes
1	4	Close crotch seam	Hind trousers on top Lining down	Automatical sewing with contour guide
2	6	Close crotch seam	Hind trousers down Lining on top	Automatical sewing with contour guide
3	4 6	Close crotch seam Close crotch seam		Alternate sewing
4	7	Close side seam	Hind trousers on top Lining down	Manual sewing and guiding in the hip bow area afterwards automatical sewing
5	5	Close side seam	Hind trousers down Lining on top	Close side seam manual sewing and guiding afterwards automatical sewing
6	7 5	Close side seam Close side seam		Alternate sewing
7	5	Close side seam	Hind trousers down Lining on top	Automatical sewing with contour guide
8	7	Close side seam	Hind trousers on top Lining down	Automatical sewing with contour guide
9	5 7	Close side seam Close side seam		Alternate sewing

6.4 Adjusting the control



The parameter values are altered in the individual parameter menus.

- Press key "P".
- Select the menu item.
- Select the parameter to be altered with the keys "F1" or "F2".
- Press key "E".
- Alter the parameter value with the keys "Plus" or "Minus".
- Press key "P".
The new parameter value is stored.
- Press key "P".
You return to the selection menu.
- Press key "P".
You return to the sewing program.


Fullness distribution with needle and bottom feed

According to the equipment of the sewing station the parameters for the needle and bottom feed are occupied differently.

The sketches below show the individual lines.




6.4.1 Altering seam-specific parameters



Needle feed (with cylinder)

Via this parameter the needle feed is set.


Parameter 01:	Line 1
	Number of stitches until the needle feed engages
Setting range:	0 - 2000
Parameter 02:	Fullness line 1 ON/ OFF
Setting range:	0 / 1
Parameter 03:	Line 2
	Number of stitches how long the needle feed is engaged
Setting range:	0 - 2000
Parameter 04:	Fullness line 2 ON/ OFF
Setting range:	0/1
Parameter 05:	Line 3
	Number of stitches how long the needle feed is engaged
Setting range:	0 - 2000
Parameter 06:	Fullness line 3 ON/ OFF
Setting range:	0/1



Needle feed (with step motor)

Via this parameter the needle feed with step motor drive is set.


Parameter 01:	Line 1
	Number of stitches
Setting range:	0 - 2000
Parameter 02:	Fullness in line 1
Setting range:	0 - 2000
Parameter 03:	Line 2
	Number of stitches
Setting range:	0 - 2000
Parameter 04:	Fullness in line 2
Setting range:	0 - 2000
Parameter 05:	Line 3
	Number of stitches
Setting range:	0 - 2000
Parameter 06:	Fullness in line 3
Setting range:	0 - 2000



Bottom feed (with cylinder)

Via this parameter the differential feed is set.


- Parameter 07: Line 1
Number of stitches until the differential bottom feed engages
Setting range: 0 - 2000
- Parameter 08: Fullness line 1 ON/ OFF
Setting range: 0 / 1
- Parameter 09: Line 2
Number of stitches how long the differential bottom feed is engaged
Setting range: 0 - 2000
- Parameter 10: Fullness line 2 ON/ OFF
Setting range: 0 / 1
- Parameter 11: Line 3
Number of stitches how long the differential bottom feed is engaged
Setting range: 0 - 2000
- Parameter 12: Fullness line 2 ON/ OFF
Setting range: 0 / 1



Bottom feed (with step motor)

Via this parameter the differential feed with step motor drive is set.

- Parameter 07: Line 1
Number of stitches
Setting range: 0 - 2000
- Parameter 08: Fullness in line 1
Setting range: 0 - 2000
- Parameter 09: Line 2
Number of stitches
Setting range: 0 - 2000
- Parameter 10: Fullness in line 2
Setting range: 0 - 2000
- Parameter 11: Line 3
Number of stitches
Setting range: 0 - 2000
- Parameter 12: Fullness in line 3
Setting range: 0 - 2000




Setting the ejector roller

Via this parameter the ejector roller is set.

- Parameter 16: Number of stitches how long the seam chain is sucked (seam beginning)
Setting range: 0...120
- Parameter 17: Switch the stacker on or off
Setting range: 0 / 1
- Parameter 20: Number of stitches when the ejector roller lowers
Setting range: 0 ...400 stitches
- Parameter 21: Number of stitches how long the ejector roller is switched on
Setting range: 0 ...400 stitches
- Parameter 22: Number of stitches after "light barrier bright", until the ejector roller stops
Setting range: 0 ...30 stitches
- Parameter 23: Time how long the ejector roller is active
Setting range: 0 ...1000
- Parameter 47: Time of the stacker movement
Input: 0 ...2000
- Parameter 53: Time when the ejector roller lifts
Setting range: 0 ...2000


1



Setting the puller

Via this parameter the puller is set.

- Parameter 26: Number of stitches when the puller lowers
Setting range: 0 ...400 stitches
- Parameter 27: Number of stitches how long the puller remains lowered
Setting range: 0 ...400 stitches
- Parameter 51: Puller speed
lower value = increased puller speed
higher value = lower puller speed
Setting range: 400 ... 1000
- Parameter 100: Number of stitches how long the puller lifts
Setting range: 0...400 stitches



Altering the machine parameters

Parameter 30: Set the main speed
Setting range: 0 - 6500

Parameter 31: Manual sewing on/ off
Setting range: 0 / 1

Parameter 32: Number of stitches how long the table blowing
remains switched on
Setting range: 0 ...400 stitches

Parameter 33: Number of stitches until the automatic start engages
after the sewing start
Setting range: 0 ...

Parameter 34: Number of stitches until the contour guide lowers
Setting range: 0 ...400 stitches

Parameter 35: Number of stitches until the contour guide retracts
laterally
Setting range: 0 ...400 stitches

Parameter 36: Number of stitches until the feeding unit lowers
Setting range: 0 ...400

Parameter 37: Start mode contour modulation
1 = front, left
2 = rear, right
3 = rear, left
Setting range: Modes 1, 2, 3

Parameter 60: Soft start speed
Setting range: 500 ...5000

Parameter 61: Switch the soft start on or off
Setting range: 0 / 1

Parameter 76: Switch the start on or off via light barrier
Setting range: 0 / 1

Parameter 77: Switch the autostart on or off
Setting range: 0 / 1

Parameter 78: Number of stitches until the autostart starts
Setting range: 0 ...400 stitches



Altering the potentiometer

Parameter 18: Needle feed potentiometer Off / On
Setting range: 0 / 1

Parameter 19: Differential feed potentiometer Off / On
Setting range: 0 / 1

Parameter 24: Line 1,
Needle feed potentiometer Off / On
Setting range: 0 / 1


Parameter 25: Line 2,
Needle feed potentiometer Off / On
Setting range: 0 / 1

Parameter 28: Line 3,
Needle feed potentiometer Off / On
Setting range: 0 / 1

Parameter 96: Line 1,
Differential feed potentiometer Off / On
Setting range: 0 / 1

Parameter 97: Line 2,
Differential feed potentiometer Off / On
Setting range: 0 / 1

Parameter 99: Line 3,
Differential feed potentiometer Off / On
Setting range: 0 / 1



Setting the seam line

Parameter 81:	Length of line 1
Setting range:	0 ...
Parameter 82:	Line 1 Reduced speed Off / On
Setting range:	0 / 1
Parameter 83:	Line 1 Reduced speed
Setting range:	500...6500
Parameter 84:	Line 1 Stop at the end of the line Off / On
Setting range:	0 / 1
Parameter 85:	Line 1 Sewing foot lift at the end of the line Off / On
Setting range:	0 / 1
Parameter 86:	Length of line 2
Setting range:	0 ...
Parameter 87:	Line 2 Reduced speed Off / On
Setting range:	0 / 1
Parameter 88:	Line 2 Reduced speed
Setting range:	500...6500
Parameter 89:	Line 2 Stop at the end of the line Off / On
Setting range:	0 / 1
Parameter 91:	Length of line 3
Setting range:	0 ...
Parameter 92:	Line 3 Reduced speed Off / On
Setting range:	0 / 1
Parameter 93:	Line 3 Reduced speed
Setting range:	500...6500
Parameter 94:	Line 3 Stop at the end of the line Off / On
Setting range:	0 / 1

Altering global parameters

- Parameter 58: Display of the software version
- Parameter 59: Number of stitches how long the seam chain is sucked (seam beginning)
Input: 0 ...50
- Parameter 65: Thread tension lift
Input: 0 ...50
- Parameter 79: Soft start after "Stop in the seam"
Input: 0 ...500

6.4.3 Input - Output test

Via the input - output test the different input and output elements can be checked.

Input test

- Press key "**P**".
- Press key "**8**".
- Actuate the corresponding input.
Example:
Cover the light barrier.
- Press key "**Program stop**".
The program is quitted.

Input elements	
Switch	Designation
01	Light barrier 01 start
05	Switch "Program stop"
06	Mouse back
11	Potentiometer needle feed and differential bottom feed (optional equipment)
12	Potentiometer puller (optional equipment)

Output test


- Press key "**P**".
- Press key "**8**".
- Press key "**Plus**".
- Select the output element to be tested with the keys "**Plus**" or "**Minus**".
- Switch the output on or off with the key "F2".
- Press key "**Program stop**".
The program is quitted.

Output elements	
Switch	Designation
Y01	Sewing foot up / down
Y02	Thread tension lift open
Y03	Contour guide up / down
Y04	Stacker off / on
Y05	Ejector roller up / down
Y06	Feeding unit up / down
Y07	Contour guide forward / backward
Y08	Contour guide blowing on
Y09	Move contour guide laterally
Y10	Differential bottom feed on / off
Y11	Needle feed on / off
Y12	Warp separator off / on
Y13	Table blowing off / on
Y14	Dirt suction off / on
Y15	Puller up / down
Y16	Mouse back


6.4.4 Creation of seam programs

Note

Before a new seam program can be created or an existing one can be deleted, the global parameter "56" has to be set to the value "0". This avoids that the existing programs are changed inadvertently.




Creating a seam program



Note

After the creation of a new seam program the parameter "56" has to be reset to the value "1" for safety reasons.


6.4.5 Deleting a seam program



6.4.6 Altering seam programs (Changing / Completing the sequence)

Note

Before a seam program can be altered, the parameter "56" has to be set to the value "1". This avoids that the existing programs are deleted inadvertently. (see chapter 6.4.3, paragraph 1)



7. Error messages

In case of an error in the control system or in the machine program corresponding error messages are indicated in the display.

Display	Meaning
Error 1	One of the parameters "18" or "19" is switched on (value = 1)
Error 2	Both parameters "18" and "19" are switched on (value = 1)
Error 3	In the current program the last existing seam was to be deleted.

Errors of free programming

Info U1	FP custom code wrong, e.g. describing a parameter which does not exist.
Info U2	Wrong system function
Info U3	Wrong in / out number
Info U4	Too many user variables
Info U5	Too many system variables
Info U6	Not enough storage location for the user program
Info U7	Wrong or undefined key in the Vario
Info U8	Unknown device address
Info U9	Fatal exception error

Errors and informations bootloader

Info B1	Switch on control in the boot mode and press key "F2"
Info B2	Programming of segment number
Info B3	Flash programming failed
Info B4	Flash programming okay

8. USB stick

8.1 General notes



The USB stick 1 serves for storing and transferring of the sewing unit software.

By means of the USB stick program and parameter data can also be transferred to other sewing units.

Commercially available USB 1 sticks can be used, too.

1

8.2 Formatting the USB stick

Before using a new USB stick this has to be formatted correspondingly. The file format is the “**FAT 16**” system.

- Format the USB stick with the FAT 16 system via a PC.

8.3 Plugging the USB stick in the control

- Switch the main switch off.
 - Plug the USB stick 1 in the lower slot of the Efka control.
 - Press key “**P**” and keep it pressed.
- P**
- Switch the main switch on. The message appears for a moment.
- P**
- USB. DEV. DETECT:
- Keep key “**P**” pressed until the following message appears in the display:
- SERVICE - CODE
- 3** **1** **1** **2**
- Enter CODE 3112.
- E**
- Press key “**E**”.

8.4 USB functions

The following functions can be carried out with a USB stick:

1) Storing and loading of global parameters

File extension = *.PAR

Parameter	Function
F-510	Securing from the control on the USB stick
F-511	Loading from the USB stick in the control
F-512	Comparing USB stick and control data
F-513	Deleting data from the USB stick

2) Storing and loading of programs and seam parameters

File extension = *.PAY


Parameter	Function
F-514	Securing from the control on the USB stick
F-515	Loading from the USB stick in the control
F-516	Comparing USB stick and control data
F-517	Deleting data from the USB stick

3) Loading a new software version

File extension = *.PRG

Parameter	Function
F-523 stick in the	Load a new software version from the USB control

By means of the FAT 16 file system the control allocates file names with max. 8 characters.



If different program or parameter files are stored, the control allocates a new name each.

Example:

Storing of different parameter data

1st file 0100DATA.PAR

2nd file 0101DATA.PAR


etc.

The files can individually be renamed by the file manager or explorer on a PC.

Note

On principle, the Efka control can read data from the main level of the USB stick only. Data from subdirectories cannot be processed.


8.4.1 Storing data on the USB stick




Note

The file name is allocated automatically.

8.4.2 Loading data from the USB stick



8.4.3 Data comparison




Possible displays


DATA OK	The data on the stick are identical with the data of the control
DATA DIFFERENT	The data of the stick and the control are not identical.

1

8.4.4 Deleting data from the USB stick



8.4.5 Loading software version from the USB stick



8.5 Removing the USB stick



- Switch the main switch off.
- Pull the USB stick 1 out of the slot of the Efka control.

1

9. Maintenance

9.1 Cleaning and checking



Caution: Risk of injury !


Switch the main switch off.

The maintenance of the engineered sewing station must only be carried out with the machine switched off.

Maintenance work has to be done after the intervals indicated in the tables at the latest (see column "Operating hours").

The processing of fluffy material may require shorter maintenance intervals.

A clean sewing station protects from disturbances.



1



2



6


5

4

3

Maintenance work to be done	Explanation	Operating hours
Machine head		
- Remove sewing dust and thread remainders. (e.g. with compressed air pistol)	Clean the entire area 1 of the thread guides under the fabric sliding sheet	8
Suction device		
	Empty container 2 of the suction device - Turn the bottom part of the container to the left and remove it - Empty the container - Screw the bottom part on again in clockwise direction	8
Pneumatic system		
- Check the water level in the pressure regulator 3	The water level must not rise up to the filter insert 4. - Let the water run out of the water separator under pressure after pressing the drain plug 5.	40
- Clean the filter insert 4	The filter insert 4 separates dirt and condensed water. - Separate the sewing unit from the compressed air net. - Push in drain plug 5. The pneumatic system of the sewing unit has to be pressureless. - Screw the water separator 6 off - Remove filter insert 4. Wash the dirty filter tray and the filter insert with benzine (no solvent!) and blow them clean. - Reassemble the water separator and connect the maintenance unit.	500
- Make leak test of the system		500

9.2 Oil lubrication



Caution: Risk of injury !

Oil may cause skin eruption.
Avoid a longer contact with the skin.
Wash yourself thoroughly after a contact.



ATTENTION !

The handling and disposal of mineral oils is subject to legal regulations.
Deliver used oil to an authorized collecting station.
Conserve your environment.
Be careful not to spill any oil.

Oil the head of the sewing unit exclusively with lubricating oil **DA-10** or an equivalent oil with the following specification:

- Viscosity at 40° C: 10 mm²/s
- Ignition point: 150° C

DA-10 can be bought at the sales points of **DÜRKOPP ADLER AG** under the following parts numbers:

Container 250 ml:	9047 000011
Container 1 litre:	9047 000012
Container 2 litres:	9047 000013
Container 5 litres:	9047 000014

Maintenance work to be done	Explanation	Operating hours
Lubrication	<p>Check the oil level at the sewing machine head regularly (inspection glass 1 and 2).</p> <p>Please take further details from the enclosed operating instructions of the sewing machine head.</p>	8

Part 2: Assembly instructions cl. 1281/5

1. Scope of delivery 3

2. General notes 3

3. Installing the sewing unit 4

3.1 Transport protections 4

3.2 Setting the working height 5

3.3 Mounting the thread reel holder. 6

3.4 Mounting the material rests 6

4. Electrical connection 7


4.1 Checking the nominal voltage 7

4.2 Making the mains connection 7

5. Pneumatic connection 8

6. Putting into operation 9

6.1 Sewing test 9



1. Scope of delivery

The scope of delivery **depends on your order**.
The sewing unit consists of:

- 1 Sewing machine head (as per order)
- 2 Thread reel holder
- 3 Control with control panel
- 4 Material rests
- 5 Stand and table top
- 6 Foot pedal
- 7 Suction unit with suction container
- 8 Stacker
- 9 Feeding unit with puller
- Compressed air maintenance unit with compressed air pistol

2. General notes

2



ATTENTION !


The sewing unit must only be installed by trained specialist staff.

Any work on the electrical equipment of the sewing unit must only be carried out by electricians or correspondingly instructed persons. The mains plug must be pulled out.

The enclosed operating instructions of the drive motor manufacturer have to be observed.



3. Installing the sewing unit

3.1 Transport protections



Before the installation of the sewing unit all transport protections have to be removed.

- Remove the security tapes at the thread reel holder, machine table etc.
- Remove the protective foils 1.
- Remove the security tapes 2 from the stacker.



- Remove the protections from the mouse 4 and the reverse device 3.

3.2 Setting the working height




The working height is adjustable between 850 and 1200 mm (measured up to the top edge of the table top).

- Loosen screws 1 at the spars.
- Set the desired working height with the help of suitable auxiliary means.
In order to avoid jamming lift the table top equally on both sides.
- Retighten screws 1 at the spars.



2

3.3 Mounting the thread reel holder



- Insert thread reel holder 1 in retainer 2.
- Tighten the thread reel holder with the two screws 3.

3.4 Mounting the material rests



The material rests have be demounted for transportation.

- Loosen the screws 2 at the fixtures 3.
- Insert the bars 1 in the fixtures 3.
- Retighten the screws 2 at the fixtures 3.
- Loosen the screws at the fixtures 4 and 5 and align the height of the material rests.
- Retighten the screws at the fixtures 4 and 5.

4. Electrical connection



ATTENTION !

Any work on the electrical equipment of the sewing unit must only be carried out by electricians or correspondingly instructed persons. The mains plug must be pulled out.

4.1 Checking the nominal voltage



ATTENTION !

The nominal voltage indicated on the type plate of the sewing machine control and the mains voltage must correspond.

Nominal voltage = 190 - 240 V, 50/60 Hz

4.2 Making the mains connection

- Connect the mains plug.

5. Pneumatic connection

For the operation of the pneumatic components the sewing unit has to be provided with anhydrous compressed air.




ATTENTION!

For a trouble-free function of the pneumatic control processes the compressed air net has to be rated as follows:

Even in the moment of maximum air consumption the minimum operating pressure must not drop below **6 bar**.

In case of a too high air pressure decrease:

- Increase the compressor output.
- Increase the diameter of the compressed air supply line.



Connecting the compressed air maintenance unit

- Connect the connecting hose 3 to the compressed air net.

Setting the operating pressure

- The operating pressure amounts to 6 bar. It can be read off at the manometer 1.
- For setting the operating pressure pull up and turn the rotary handle 2.
 - Turn in clockwise direction = increase the pressure
 - Turn counter-clockwise = reduce the pressure



ATTENTION !

No oil-bearing compressed air must be fed from the compressed air net.

Behind the filter cleaned compressed air is withdrawn as blowing air for cleaning machine parts and for blowing workpieces out.

Oil particles contained in the blowing air lead to malfunction and stains on the workpieces.

6. Putting into operation

6.1 Sewing test

After completion of the installation work a sewing test should be made.

- Plug in the mains plug.



Caution: Risk of injury!

Switch the main switch off.

Thread in needle and hook thread only with the sewing unit switched off.

- Thread in needle and hook thread (see operating instructions of the sewing machine head).
- Switch the main switch on. The control is initialized.
- Select the sewing program.
- For feeding and operating see part 1: Operating instructions 1281/5

Für Ihre Notizen:

Part 3: Service instructions class 1281/5

1.	General notes	3
2.	Brief instructions for the sewing head	
2.1	Adjusting the height of the needle bar	4
2.2	Adjusting the hook	5
2.2.1	Distance between left hook and needle.	5
2.2.2	Distance between right hook and needle	7
2.3	Adjusting the needle protection	9
2.3.1	Hind needle protection.	9
2.3.2	Front needle protection	10
2.4	Adjusting the feed-dog.	11
2.4.1	Feed-dog position	11
2.4.2	Feed-dog height	12
2.5	Presser foot	13
2.5.1	Presser foot lift Head EXT 3216	13
2.5.2	Presser foot	14
2.6	Upper and lower knife	15
2.6.1	Changing and adjusting the upper knife	15
2.6.2	Changing and adjusting the lower knife	16
2.7	Thread regulation overlock hook.	17
3.	Adjusting the sewing unit	
3.1	Adjusting the light barrier	18
3.2	Adjusting the material stop	19
3.3	Adjusting the contour guide.	20
3.4	Direct sewing drive	21
3.4.1	Setting the reference.	21
4.	Oil lubrication	
4.1	Oil change and oil filter change	22
5.	Maintenance	23

1. General notes

The service instructions on hand describe the adjustment of the single-head overlock unit 1281/5.

The manual consists of:

- Brief instructions for the sewing head
- Service instructions for the sewing unit



ATTENTION !

The brief instructions are a summary of the detailed operating instructions of the sewing head. In any case these operating instructions have to be carefully read and all regulations have to be observed. The Beisler company does not guarantee the accuracy of the following specifications.



ATTENTION !

The operations described in the service instructions must only be executed by qualified staff or correspondingly instructed persons respectively!



Caution: Risk of injury !

In case of repair, alteration or maintenance work switch the main switch off.

Carry out adjusting operations and functional tests of the running machine only under observation of all safety measures and with utmost caution.

The instruction manual on hand describes the adjustment of the sewing unit in an appropriate sequence.



Please observe in this connection that various setting positions are interdependent.

Therefore it is absolutely necessary to do the adjustment following the described order.

For all setting operations of parts involved in the stitch formation a new needle without damage has to be inserted.

2. Brief instructions for the sewing head


2.1 Adjusting the height of the needle bar



Caution: Risk of injury!

Switch the main switch off.

Check and adjust the height of the needle bar only with the sewing unit switched off.



Standard checking

In the top dead centre of the needle bar the distance between the needlepoint 4 and the throat plate should amount to 9.7 - 9.9 mm.



- Move the needle bar in its top dead centre.
- Check whether the distance between needlepoint 4 and throat plate 5 amounts to 9.7 - 9.9 mm.

Correction

- Unscrew screws 1 and remove cover 2.
- Move the needle bar in its top dead centre.
- Swivel the sewing foot out.
- Loosen screw 3 until the needle bar can just be pushed.
- Shift the needle bar in such a way that the distance between needlepoint 4 and throat plate amounts to 9.7 - 9.9 mm.
- Tighten screw 3.
- Screw cover 2 on again.

2.2 Adjusting the hook

2.2.1 Distance between left hook and needle



Caution: Risk of injury!

Switch the main switch off.

Check and adjust the hook only with the sewing unit switched off.

3

Cross-line adjustment

Standard checking

In the left reverse point of hook 5 the distance between the middle of the needle and the hook tip should amount to 2.3 - 2.5 mm.



- Move the **left** hook in its **left** reverse point by handwheel.
- Check whether the distance between the middle of the needle and the hook tip amounts to 2.3 - 2.5 mm.

Correction

- Unscrew the throat plate, the front feed-dog as well as the front and hind needle protection.
- Move the hook in its left reverse point by handwheel.
- Loosen screw 1 and take care that the hook abuts on stop 2.
- Tighten screw 1 again.
- Loosen screw 4 until the hook support 3 can just be turned.
- Turn the hook support in such a way that the distance between the middle of the needle and the hook tip amounts to 2.3 - 2.5 mm.

Note

Do not yet tighten screw 4.





Adjustment in sewing direction

Standard checking

The distance between hook tip 6 and needle 7 should amount to 0.0 - 0.05 mm.

- Turn handwheel in direction of rotation until the hook tip is exactly at the level of the middle of the needle.
- Shift the hook support 3 in such a way that the distance between hook support and needle amounts to 0.0 - 0.05 mm.
- Check the cross-line adjustment once again and readjust, if necessary.
- Tighten screw 4.

2.2.2 Distance between right hook and needle



Caution: Risk of injury!

Switch the main switch off.

Check and adjust the hook only with the sewing unit switched off.

3

Cross-line adjustment


Standard checking



When the **right** hook is in its top reverse point, the distance between hook tip 9 and the middle of the needle should amount to 4.3 - 4.5 mm.

- Screw off thread guides 1 and 3 as well as cover 2.
- Move the hook in its top dead centre by handwheel.
- Loosen screw 4 until the hook can just be pushed.
- Shift the hook in such a way that the hook shank (1) is flush with the right side of the hook holder.
- Loosen screw 6 a little.
- Turn lever 5 in such a way that there is a distance of 4.3 - 4.5 mm between hook tip and the middle of the needle.
Take care that the bar 8 in the bearing 7 does not move too heavy.
- Tighten screw 6.

Note

Do not yet tighten screw 4.





Adjustment in sewing direction

Standard checking

When the right hook crosses the left hook, the distance "A" should amount to 0.5 mm and the distance "B" to 0.2 mm.

Correction



- Turn handwheel in direction of rotation until the right hook crosses the left hook.
- Turn and shift the right hook in such a way that the distance "A" amounts to 0.5 mm and the distance "B" to 0.2 mm.
- Tighten screw 4 in this position.
- Check all adjustments once again and readjust, if necessary.
- Remount thread guides 1 and 3 as well as cover 2.
- Adjust thread guides according to chapter "thread regulation of the overlock hooks".

Note

The right overlock hook is dependent on the needle size.
Use hook No. 28 for needles Nm 60 - 80 and hook No. 22 for needles Nm 80 - 100.

2.3 Adjusting the needle protection

2.3.1 Hind needle protection



Caution: Risk of injury!

Switch the main switch off.

Check and adjust the needle protection only with the sewing unit switched off.

3


Standard checking

When the tip of the left hook 3 is at the level of the middle of the needle, the needle protection 1 should abut on the needle. There should be a distance of 0.0 - 0.05 mm between hook tip and needle.

- Turn handwheel in direction of rotation until the hook tip points in the needle direction.
- Check the distance between hook tip and needle.

Correction of the mobile version



- Turn handwheel in direction of rotation until the hook tip points in the needle direction.
- Loosen screw 2.
- Shift the needle protection 1 in such a way that it abuts on the needle and there is a distance of 0.0 - 0.05 mm between hook tip and the middle of the needle.
- Tighten screw 1.



Correction of the stationary version

- Turn handwheel in direction of rotation until the hook tip points in the needle direction.
- Loosen screws 4.
- Shift the needle protection 3 in such a way that it abuts on the needle and there is a distance of 0.0 - 0.05 mm between hook tip and the middle of the needle.
- Tighten screws 4.

2.3.2 Front needle protection



Caution: Risk of injury!

Switch the main switch off.

Check and adjust the needle protection only with the sewing unit switched off.

Standard checking

In the lower dead centre of the needle the distance between needle protection 1 and needle should amount to 0.03 - 0.05 mm.



- Turn handwheel in direction of rotation until the needle is in its lower dead centre.
- Check the position of the front needle protection.

Correction

- Turn handwheel in direction of rotation until the needle is in its lower dead centre.
- Loosen screw 2.
- Shift the needle protection 1 in such a way that there is a distance of 0.03 - 0.05 mm between needle protection and needle.
- Tighten screw 2.

2.4 Adjusting the feed-dog

2.4.1 Feed-dog position



Caution: Risk of injury!

Switch the main switch off.

Check and adjust the feed-dog position only with the sewing unit switched off.

3

Standard checking

In their highest position the feed-dogs should be horizontal.

- Turn handwheel in direction of rotation until the feed-dogs are in their highest position.
- Check the position of the feed-dogs.

Correction

- Turn handwheel in direction of rotation until the feed-dogs are in their highest position.
- Loosen screw 1.
- Turn screw 2.



Feed-dogs are horizontal




Feed-dogs are inclined backwards



Feed-dogs are inclined forwards

- Tighten screw 1.

2.4.2 Feed-dog height



Caution: Risk of injury!

Switch the main switch off.

Check and adjust the feed-dog height only with the sewing unit switched off.

Standard checking

When the feed-dogs are in their highest position, the teeth of the main feed-dog 4 should be 0.8 mm above the top edge of the throat plate, the teeth of the differential feed-dog 5 0.9 to 1.0 mm and the teeth of the auxiliary feed-dog 6 0.6 to 0.7 mm.


- Turn the handwheel in direction of rotation until the feed-dogs are in their highest position.
- Check the position of the feed-dogs to the throat plate.

Correction

- Unscrew throat plate.
- Loosen screws 1, 2 and 3 a little.
- Put throat plate on again.
- Set the height of the feed-dogs.
- Remove the throat plate.
- Tighten screws 1, 2 and 3.
- Put throat plate on again and tighten.

2.5 Presser foot

2.5.1 Presser foot lift Head EXT 3216




Caution: Risk of injury!

Switch the main switch off.

Check and adjust the presser foot lift only with the sewing unit switched off.

3



Standard

When the piston rod 7 is extended, the lever 6 should abut on screw 5 and the clearance under the sewing feet should amount to 4 mm.

Correction


- Loosen counternut 4 and screw the screw 5 down completely.
- Swivel the sewing foot in.
- Turn handwheel in direction of rotation until the teeth of the feed-dog are underneath the top edge of the throat plate.
- Loosen screw 2 and press ring 1 backwards as far as it will go.
- Tighten screw 2 in this position.
Take care that ring 1 and lever 3 have no axial backlash.
- Press lever 6 down until there is a distance of approx. 4 mm between sewing foot and throat plate.
- Let screw 5 abut on lever 6 in this position and fix it by a locknut.

Note


If lever 6 does not abut on screw 5 when the piston rod 7 of the cylinder is extended, please proceed as follows:

- Loosen nut 8.
- Shift cylinder 1 correspondingly.
- Tighten nut 8.

2.5.2 Presser foot



4 3 2 1



5 4



Caution: Risk of injury!

Switch the main switch off.

Check and adjust the presser foot only with the sewing unit switched off.

Standard

The hinges of the hinged sewing foot must be free of clearance and smooth-running.

The front sewing foot sole 1 and the hind sewing foot soles 4 have to be in parallel position.

Correction of lateral inclination

- Remove the front sewing foot sole 1.
- Bring the head into position “needle down”.
- Place two approx. 5 mm wide paper strips 5 next to each other under the hind sewing foot sole 4.
- Adjust the lateral inclination in such a way that the inner paper strip is clamped a little less than the outer one and can be easily pulled out of the clamping of the sewing foot.

Compensation of the front and hind sewing foot sole

- Remount the front sewing foot sole 1.
- Bring the head into position “needle down”.
- Turn the setting screw 3 in such a way that the front sewing foot sole just rests on.

Inclination of the front sewing foot sole


The whole length of the front sewing foot sole should rest on the throat plate in the position “needle down”.

- Set the sewing foot sole with screw 2.

2.6 Upper and lower knife

2.6.1 Changing and adjusting the upper knife

Head EXT 32-16-03/233K



Caution: Risk of injury!

Switch the main switch off.

Change and adjust the upper knife only with the sewing unit switched off.

3

Standard


In the lowest position of the upper knife the front edge of the blade should be 0.5 to 1.0 mm underneath the top edge of the throat plate.

Correction

- Turn the handwheel until the needles are in their top reverse point and swivel the sewing foot out.
- Screw off screw 1.
- Remove the knife holder 2 with the knife.
- Loosen screw 3 and remove the knife.
- Insert a new, sharp knife and tighten with screw 3.
- Insert knife holder 2 and tighten slightly with screw 1.
- Turn the handwheel until the knife is in its lowest position.
- Shift the knife in such a way that it slightly abuts on the lower knife and the front edge of the blade is approx. 0.5 to 1.0 mm underneath the top edge of the throat plate.

2.6.2 Changing and adjusting the lower knife

Head EXT 3216-03/233K



Caution: Risk of injury!

Switch the main switch off.

Change and adjust the lower knife only with the sewing unit switched off.


Standard

The blade of the lower knife has to be flush with the top edge of the throat plate.

Correction

- Remove the fabric sliding sheet.
- Swivel the sewing foot out.
- Loosen screw 4.
- Draw the holder of the lower knife 3 to the left as far as it will go and tighten screw 4 slightly.
- Loosen screw 2 and remove the old knife.
- Insert a new, sharp knife in guide 1 in such a way that the blade is flush with the top edge of the throat plate.
- Tighten screw 2.
- Turn the handwheel until the upper knife is in its highest position.
- Loosen screw 4 and let the holder of the lower knife 3 spring against the upper knife.
- Tighten screw 4.

2.7 Thread regulation of overlock hook



Caution: Risk of injury!

Switch the main switch off.

Check and adjust the thread regulation only with the sewing station switched off.

3

Standard

The position of the individual thread guides or thread pullers is dependent on the material, the sewing thread and the stitch type. Therefore the following setting values have to be regarded as standard values only.

Correction

- Turn the handwheel until the right hook is in its top reverse point.
- Loosen screw 10 and shift the thread puller 9 in such a way that there is a distance of approx. 32 mm between the middle of the screw and the middle of the eyelet.
- Tighten screw 10.
Take care that the thread puller 9 is in vertical position.
- Loosen screws 6 and 8 a little.
- Position the thread pullers 3 and 7 as shown in the illustration.
- Tighten screws 6 and 8.
- Loosen screw 4 a little.
- Position the thread guide 5 as shown in the illustration.
- Tighten screw 4.
- Loosen screw 2 a little.
- Shift the thread guide 1 in such a way that the screw 2 is in the centre of the longitudinal hole.
- Tighten screw 2.

Note

If the seam requires more or less thread, shift the thread pullers 3 and 7 in the direction "+" or "-" respectively.

3. Adjusting the sewing unit

3.1 Adjusting the light barrier



2

1



5

4

3



Caution: Risk of injury!

The adjustment of the light barrier is done with the sewing unit switched on.

Carry out adjustment and function test with utmost caution.



6

5

Aligning the light barrier

The light barrier 2 has to be aligned to the area 1 of the machine head.


- Loosen screws 4 and 5.
- Align the light barrier support 3 correspondingly.
- Tighten screws 4 and 5.

Adjusting the light barrier intensity

- Turn the sensitivity potentiometer 5 at the front above the light-emitting diode 6 to the left stop (minimum sensitivity).
- Turn the potentiometer in clockwise direction until the light-emitting diode 6 switches on.
- For a safe light barrier function turn the potentiometer once again in clockwise direction.

If the light-emitting diode does not shine, the light barrier should be cleaned, reset or exchanged.

3.2 Adjusting the material stop



Caution: Risk of injury!

Switch the main switch off.

Adjust the material stop only with the sewing unit switched off.

3

Standard

The material stop 2 must completely abut on the sewing foot 3 so that the material cannot be pushed upward between sewing foot 3 and stop 2.

Correction

- Loosen screws 1.
- Push the material stop 2 completely against the sewing foot 3.
- Tighten screws 1.

3.3 Adjusting the contour guide



2

1



1

3



Caution: Risk of injury!

Switch the main switch off.

Adjust the contour guide only with the sewing unit switched off.

Standard

The contour guide 1 should move forward as far as to ensure that both material plies 2 are always guided safely when sewing the contour.

Correction of the swivelling width


- Loosen the clamping lever 3.
- Shift the contour guide 1 correspondingly.
- Tighten the clamping lever 3.

Correction of the stamp position

- Loosen nut 6.
- Turn the stamp 1 correspondingly.
- Tighten nut 6.

3.4 Direct sewing drive

3.4.1 Setting the reference



Caution: Risk of injury!

Switch the main switch off.

Check and adjust the hook setting only with the sewing unit switched off.


3

Standard

When the needle is in the position “**7 mm after the bottom dead centre**”, the drive belt has to be put on in such a way that the feather key 2 in the motor shaft points to the marking 1 in the motor casing.

Correction

- Remove the toothed belt.
- Move the needle bar in the position “**7 mm after the bottom dead centre**” by handwheel.
- Turn the motor shaft in such a way that the feather key 2 in the motor shaft points to the marking 1 in the motor casing.
- Put the toothed belt on again.



4. Oil lubrication



Caution: Risk of injury !




Oil can cause skin eruption.
Avoid a longer contact with the skin.
Wash yourself thoroughly after a contact.



ATTENTION !

The handling and disposal of mineral oils is subject to legal regulations.
Deliver used oil to an authorized collecting station.
Conserve your environment.
Be careful not to spill any oil.

4.1 Oil change and oil filter change



4 weeks after the initial start-up and subsequently every two years an oil change has to be carried out with the machine head disassembled.

The oil filter should be cleaned or exchanged every two years.

Note

If the oil pressure gauge 5 does not move downwards when the machine head is running or if the oil is dirty, the oil filter has to be cleaned or exchanged.

- Unscrew the drain screw 1 and collect the used oil in a collecting basin.
- Screw drain screw 1 in again.
- Unscrew screws 6 of the cover.
- Screw one of the screws 6 in filter 8 and unscrew the filter.
- Clean or exchange filter 8.
- Insert a new gasket 7, put the cover on again and tighten.
- Unscrew screw 2 and fill in oil until the point of the oil level indicator 3 has reached the upper marking of the oil inspection glass 4.
We recommend to use oil with a density of 0.865 g/cm³ at 15 ° C.
- Insert screw 2 again.

5. Maintenance



Caution: Risk of injury !

Switch the main switch off.

The maintenance of the sewing unit must only be done with the machine switched off.

The daily or weekly maintenance work (cleaning and oiling) to be carried out by the operators of the sewing unit is described in the operating instructions (chapter 8). This is listed in the following table for the sake of completeness only.

Maintenance work to be carried out	Operating hours			
	8	40	160	500
<p>Machine head</p> <ul style="list-style-type: none"> - Remove sewing dust and thread remainders - Check the oil level - First oil change - Subsequent oil change 	X	X	X	
		every 2 years		
<p>Control box</p> <ul style="list-style-type: none"> - Remove sewing dust and thread remainders - Keep the fan grill clean 	X			
	X			
<p>Suction device</p> <ul style="list-style-type: none"> - Empty the container - Clean the zone under the fabric sliding sheet from sewing dust and thread remainders 	X	X		
<p>Pneumatic system</p> <ul style="list-style-type: none"> - Check the water level in the pressure regulator - Clean the filter insert in the maintenance unit - Make leak test of the system 	X			X

Note: