

906

Additional Instructions

Adjusting pneumatic connection

IMPORTANT
READ CAREFULLY BEFORE USE
KEEP FOR FUTURE REFERENCE

All rights reserved.


Property of Dürkopp Adler AG and protected by copyright. Any reuse of these contents, including extracts, is prohibited without the prior written approval of Dürkopp Adler AG.

Copyright © Dürkopp Adler AG 2015

1	Exchanging pneumatic output	3
2	Performing a software update	4
3	Adjusting sewing programs	7
3.1	Making adjustments on the computer.....	7
3.2	Making adjustments on the control panel	10
4	Appendix	13

1 Exchanging pneumatic output

Fig. 1: Exchange pneumatic output 1




(1) - Screws

(2) - Cover

1. Loosen 9 screws (1) on the right cover (2).
2. Carefully remove cover (2).

Fig. 2: Exchange pneumatic output 2



(3) - Valve Y13

3. The hoses for valve Y13 (3) must be swapped. BEFORE doing so, mark which hose was inserted at which position.
4. Carefully re-fit cover (2).
5. Re-tighten 9 screws (1) of the cover (2).

2 Performing a software update

1. Download the current software version in the download area at www.duerkopp-adler.com.
2. Save the current software version, version A01 dated 16th of November 2015, to a USB key.



Information

Not all commonly available USB keys are suitable for the copying process. You can obtain a suitable USB key from Dürkopp Adler using the part number 9805 791113.

NOTICE


Property damage may occur!

A software update will delete all sewing programs stored on the machine.

Back up all sewing programs stored on the machine before performing a software update.


3. Switch off the machine.
4. Plug the USB key into the USB port of the control panel.
5. Switch on the machine.
- ↳ Transfer of software data starts.

Fig. 3: Perform a software update 1




6. Wait until the message *Please remove USB memory stick* appears on the control panel.

Fig. 4: Perform a software update 2




7. Remove the USB key from the USB port of the control panel.
- ↳ The following display appears:

Fig. 5: Perform a software update 3



8. Press the **OK** button to confirm your selection and wait.
- ↳ The update starts.

Fig. 6: Perform a software update 4



9. Press the **OK** button to confirm the message that the software update was completed successfully.
- ↪ The control panel returns to work mode, and the machine is ready for sewing.


NOTICE

Property damage may occur!

If not adjusted, sewing programs will cause a collision at the configuration set.

ALWAYS adjust sewing programs before using them.

Fig. 8: Adjustments in DA-CAD 2





4. Select *Output On 13* on the right side and use the arrow  to move it to the left side.

Fig. 9: Adjustments in DA-CAD 3






5. Select *Output Off* on the left side and enter the number of the output.
6. Move *Output off* to the right side  using the arrow.


Fig. 10: Adjustments in DA-CAD 4



7. When you are finished editing, press the **OK** button to confirm.


Fig. 11: Adjustments in DA-CAD 5



- ↩ The changes have now been adopted into the sewing program.
- 8. Save the sewing program and transfer it to a USB key.
- 9. Transfer the sewing program from the USB key to the machine,
 *Operating Instructions 906*.

3.2 Making adjustments on the control panel


Fig. 12: Adjustment on control panel 1



1. Open the menu *Edit* - *Seam program* - *Contour Adjustment* on the control panel.


↪ The following display appears:

Fig. 13: Adjustment on control panel 2




2. Use the arrow keys ◀ and ▶ to move the red square close to the technology point (TP) that needs to be adjusted.
 3. Press the **Next** button.
- ↪ The area of the red square is magnified in detail.

Fig. 14: Adjustment on control panel 3




4. Keep moving the arrow keys ◀ and ▶ stitch by stitch until the data of the technology points (TP) appears on the right side below the seam contour.
5. Keep pressing the **Next** button until the display shows *Change TechOps*.

Fig. 15: Adjustment on control panel 4




6. Use the **New** button to create a new TP with the properties *Output off* (output 13).

Fig. 16: Adjustment on control panel 5



7. Delete the old *Output on*.
8. Confirm the changes using the **OK** button.
9. Exit the menu using the button.
- ↳ The machine requests that you complete a reference run and is then ready for sewing.
10. Perform a contour test prior to sewing, *Operating Instructions 906* to check the modified settings in the sewing program.

Fig. 18: Pneumatic diagram, page 2



Wärmebehandlung:		Änderung		11.11.15		Jordan		ger.	
01.0 Änderung an Blatt 1		L-Nr.		Blau		gez.		ger.	
Benennung:		Verkstoff:		MogstLab		Klassifizierung		Teilefamilie	
Ka-Kante angedreht: Ab-Kante gebrochen		Form- u. Lagekol.		Oberflächen nach		DIN ISO 1101		DIN ISO 1302 u. DIN	
Allgemeintoleranz		DIN ISO 2768-mk		Bearb. 12.08.-14		Jordan		Jo	
DÜRKOPP ADLER AG		Gepr.		Norm		Blatt		2 / 2	
Bielefeld		9770 906001		Pneumatikplan		Teilnummer		9770 906001	
Blatt		2 / 2		Blatt		2 / 2		Blatt	



DÜRKOPP ADLER AG
Potsdamer Str. 190
33719 Bielefeld
Germany
Phone: +49 (0) 521 925 00
Email: service@duerkopp-adler.com
www.duerkopp-adler.com