



911-210-10

Service Instructions

IMPORTANT
READ CAREFULLY BEFORE USE
KEEP FOR FUTURE REFERENCE

All rights reserved.

Property of Dürkopp Adler GmbH and protected by copyright. Any reuse of these contents, including extracts, is prohibited without the prior written approval of Dürkopp Adler GmbH.

Copyright © Dürkopp Adler GmbH 2020

1	About these instructions	5
1.1	For whom are these instructions intended?	5
1.2	Representation conventions – symbols and characters	5
1.3	Other documents	7
1.4	Liability.....	7
2	Safety	9
2.1	Basic safety instructions	9
2.2	Signal words and symbols used in warnings	10
3	Working basis	13
3.1	Order of the adjustments	13
3.2	Laying the cables.....	13
3.3	Disassembling and assembling covers.....	14
3.3.1	Swiveling the machine head up and down	14
3.3.2	Disassembling and assembling the arm cover	16
3.3.3	Disassembling and assembling the head cover	17
3.3.4	Removing and placing the rear cover.....	18
3.3.5	Removing and placing the toothed belt cover	19
3.3.6	Opening and closing the hook cover	20
3.4	Flats on shafts	20
3.5	Aligning the machine head	21
3.6	Locking the machine in place	25
3.7	Putting the machine into position.....	26
4	Positioning the arm shaft crank.....	27
5	Positioning the toothed belt wheels	28
5.1	Adjusting the upper toothed belt wheel	28
5.2	Adjusting the lower toothed belt wheel	29
6	Aligning the needle bar linkage.....	30
7	Position of the hook and needle	31
7.1	Adjusting the looping stroke position	31
7.2	Adjusting the needle bar height	33
7.3	Adjusting the hook side clearance	34
7.4	Adjusting the needle guard.....	35
7.5	Adjusting the needle guide	37
8	Adjusting the bobbin case lifter	38
8.1	Adjusting the lifting gap	39
8.2	Adjusting the timing for opening	40
9	Sewing foot lift.....	41
9.1	Adjusting the stroke position drive	41
9.2	Adjusting the light barrier	42
9.3	Adjusting the left stop screw	43
9.4	Adjusting the sewing foot stroke relative to the needle bar stroke	44
9.5	Adjusting the sewing foot height.....	45
9.6	Adjusting the reference light barrier sewing axis	46


10	Adjusting the needle thread tension.....	48
10.1	Adjusting the needle thread regulator.....	48
10.2	Adjusting the thread tensioning spring	49
10.3	Calibrating the mechanical thread tension plate.....	50
10.4	Adjusting the electronical thread tension plate	52
10.5	Calibrating the electronical thread tension plate.....	53
10.6	Calibrating the electromechanical thread tension plate.....	54
11	Short thread cutter (KFA).....	60
11.1	Adjusting thread-pulling knife and control cam	61
11.2	Adjusting the locking latch	62
11.3	Adjusting the thread-pulling knife	63
11.4	Adjusting the counter blade	64
11.5	Adjusting the cutoff position.....	66
12	Thread trimmer	67
12.1	Adjusting the height of the thread-pulling knife.....	67
12.2	Adjusting the cutoff curve	68
12.3	Adjusting the cutting pressure	70
12.4	Adjusting point in time for cutting.....	71
13	Changing the presser bar	72
13.1	Disassembling the presser bar	72
13.2	Assembling the presser bar	74
14	Checking the machine zero point	76
15	Changing the drives	77
15.1	Changing the sewing motor	77
15.1.1	Disassembling the sewing motor	77
15.1.2	Assembling the sewing motor.....	78
15.2	Changing the X drive	79
15.3	Changing the Y drive	80
16	Checking the play between toothed rack and gear wheel....	82
17	Adjusting the safety release clutch	83
17.1	Engaging the safety release clutch.....	83
17.2	Adjusting the torque.....	85
18	Programming	87
18.1	Structure of the software	88
18.2	Overview of the menu structure.....	88
18.3	Starting the software.....	89
18.4	General operation of the software	92
18.4.1	Entering a password.....	92
18.4.2	Closing windows.....	93
18.4.3	Display principles.....	93
18.4.4	Scrolling the display.....	94
18.4.5	Selecting options from a list.....	94
18.4.6	Using file filters	96
18.4.7	Entering text	97
18.4.8	Entering parameter values	98

18.4.9 Switching the full-screen display on and off	99
18.4.10 Switching zoom on and off	99
18.5 Opening a seam program or seam sequence for sewing	100
18.6 Briefly sewing with modified values	101
18.6.1 Sewing with a modified thread tension	101
18.6.2 Sewing with a modified speed	102
18.7 Changing the bobbin/managing a thread breaking	102
18.7.1 Changing the bobbin	103
18.7.2 Bobbin change without a request from the program	103
18.7.3 Updating the bobbin capacity	103
18.8 Continuing a seam after an error	104
18.8.1 Continuing a seam in Repair mode after an error	104
18.8.2 Continuing a seam after thread breaking	105
18.9 Resetting the counter	106
18.10 Seam programs and seam sequences	107
18.10.1 Creating a new seam program	107
18.10.2 Performing a contour test	110
18.10.3 Editing a seam program	111
18.10.4 Creating a new seam sequence	119
18.10.5 Editing a seam sequence	120
18.10.6 Saving a seam program or seam sequence under a different name	121
18.10.7 Copying a seam program or seam sequence	122
18.10.8 Deleting a seam program or seam sequence	123
18.11 Editing machine parameters	124
18.12 Checking and changing the technical settings	130
18.12.1 Changing the password options	130
18.12.2 Changing the language	131
18.12.3 Setting date and time	131
18.12.4 Setting the brightness	132
18.12.5 Testing the touchscreen	132
18.13 Testing the functions of the machine	133
18.13.1 Testing inputs and outputs	133
18.13.2 Adjusting the stroke position	135
18.13.3 Testing the sewing motor	136
18.13.4 Calling up log displays and error lists	137
18.14 Initializing the control and performing updates	138
18.14.1 Initializing the control	139
18.14.2 Initializing the control panel	139
18.14.3 Performing an update of the control	139
18.15 DA CAD professional	140
19 Maintenance	141
19.1 Cleaning	142
19.1.1 Cleaning the machine	142
19.1.2 Cleaning the motor fan mesh	143
19.2 Lubricating	144
19.2.1 Lubricating the machine head	145
19.2.2 Lubricating the hook	146
19.3 Servicing the pneumatic system	147
19.3.1 Adjusting the operating pressure	147

19.3.2	Draining the water-oil mixture	148
19.3.3	Cleaning the filter element	149
19.4	Servicing specific components	150
19.5	Parts list.....	150
20	Decommissioning.....	151
21	Disposal.....	153
22	Troubleshooting	155
22.1	Customer Service	155
22.2	Messages of the software.....	155
22.3	Errors in sewing process	160
23	Technical data.....	163
23.1	Data and characteristic values	163
23.2	Requirements for fault-free operation.....	164
24	Appendix	165
24.1	Wiring diagram	165
24.2	Pneumatic diagram.....	175

1 About these instructions

These instructions have been prepared with utmost care. They contain information and notes intended to ensure long-term and reliable operation.


Should you notice any discrepancies or if you have improvement requests, then we would be glad to receive your feedback through **Customer Service** ( p. 155).

Consider these instructions as part of the product and keep it easily accessible.

1.1 For whom are these instructions intended?

These instructions are intended for:

- **Specialists:**
This group has the appropriate technical training for performing maintenance or repairing malfunctions.

With regard to minimum qualification and other requirements to be met by personnel, please also follow the chapter **Safety** ( p. 9).

1.2 Representation conventions – symbols and characters

Various information in these instructions is represented or highlighted by the following characters in order to facilitate easy and quick understanding:



Proper setting

Specifies proper setting.



Disturbances

Specifies the disturbances that can occur from an incorrect adjustment.



Cover

Specifies which covers must be disassembled in order to access the components to be set.



Steps to be performed when operating the machine (sewing and equipping)



Steps to be performed for service, maintenance, and installation



Steps to be performed via the software control panel

The individual steps are numbered:

1. First step
 2. Second step
 - ... The steps must always be followed in the specified order.
- Lists are marked by bullet points.



Result of performing an operation

Change to the machine or on the display/control panel.



Important

Special attention must be paid to this point when performing a step.



Information

Additional information, e.g. on alternative operating options.



Order


Specifies the work to be performed before or after an adjustment.

References



Reference to another section in these instructions.

Safety

Important warnings for the user of the machine are specifically marked. Since safety is of particular importance, hazard symbols, levels of danger and their signal words are described separately in the chapter **Safety** ( p. 9).

Location information

If no other clear location information is used in a figure, indications of **right** or **left** are always from the user's point of view.

1.3 Other documents

The machine includes components from other manufacturers. Each manufacturer has performed a hazard assessment for these purchased parts and confirmed their design compliance with applicable European and national regulations. The proper use of the built-in components is described in the corresponding manufacturer's instructions.

1.4 Liability

All information and notes in these instructions have been compiled in accordance with the latest technology and the applicable standards and regulations.

Dürkopp Adler cannot be held liable for any damage resulting from:

- Breakage and transport damages
- Failure to observe these instructions
- Improper use
- Unauthorized modifications to the machine
- Use of untrained personnel
- Use of unapproved parts

Transport

Dürkopp Adler cannot be held liable for breakage and transport damages. Inspect the delivery immediately upon receiving it. Report any damage to the last transport manager. This also applies if the packaging is not damaged.

Leave machines, equipment and packaging material in the condition in which they were found when the damage was discovered. This will ensure any claims against the transport company.

Report all other complaints to Dürkopp Adler immediately after receiving the product.

2 Safety

This chapter contains basic information for your safety. Read the instructions carefully before setting up or operating the machine. Failure to do so can result in serious injury and property damage.



2.1 Basic safety instructions

The machine may only be used as described in these instructions.

These instructions must be available at the machine's location at all times.

Work on live components and equipment is prohibited. Exceptions are defined in the DIN VDE 0105.

For the following work, switch off the machine at the main switch or disconnect the power plug:

- Replacing the needle or other sewing tools
- Leaving the workstation
- Performing maintenance work and repairs
- Threading

Missing or faulty parts could impair safety and damage the machine. Only use original parts from the manufacturer.

Transport	Use a lifting carriage or stacker to transport the machine. Raise the machine max. 20 mm and secure it to prevent it from slipping off.
Setup	The connecting cable must have a power plug approved in the relevant country. The power plug may only be assembled to the power cable by qualified specialists.
Obligations of the operator	<p>Follow the country-specific safety and accident prevention regulations and the legal regulations concerning industrial safety and the protection of the environment.</p> <p>All the warnings and safety signs on the machine must always be in legible condition. Do not remove!</p> <p>Missing or damaged warnings and safety signs must be replaced immediately.</p>
Requirements to be met by the personnel	<p>Only qualified specialists may be used for:</p> <ul style="list-style-type: none">• Setting up the machine/putting the machine into operation• Performing maintenance work and repairs• Performing work on electrical equipment <p>Only authorized persons may work on the machine and must first have understood these instructions.</p>

Operation Check the machine during operating for any externally visible damage. Stop working if you notice any changes to the machine. Report any changes to your supervisor. Do not use a damaged machine any further.

Safety equipment Safety equipment should not be disassembled or deactivated. If it is essential to disassemble or deactivate safety equipment for a repair operation, it must be assembled and put back into operation immediately afterward.



2.2 Signal words and symbols used in warnings




Warnings in the text are distinguished by color bars. The color scheme is based on the severity of the danger. Signal words indicate the severity of the danger.

Signal words Signal words and the hazard they describe:

Signal word	Meaning
DANGER	(with hazard symbol) If ignored, fatal or serious injury will result
WARNING	(with hazard symbol) If ignored, fatal or serious injury can result
CAUTION	(with hazard symbol) If ignored, moderate or minor injury can result
CAUTION	(with hazard symbol) If ignored, environmental damage can result
NOTICE	(without hazard symbol) If ignored, property damage can result

Symbols The following symbols indicate the type of danger to personnel:

Symbol	Type of danger
	General
	Electric shock

Symbol	Type of danger
	Puncture
	Crushing
	Environmental damage

Examples Examples of the layout of warnings in the text:

DANGER



Type and source of danger!

Consequences of non-compliance.

Measures for avoiding the danger.

↪ This is what a warning looks like for a hazard that will result in serious injury or even death if ignored.

WARNING



Type and source of danger!

Consequences of non-compliance.

Measures for avoiding the danger.

↪ This is what a warning looks like for a hazard that could result in serious or even fatal injury if ignored.

CAUTION



Type and source of danger!

Consequences of non-compliance.

Measures for avoiding the danger.

↪ This is what a warning looks like for a hazard that could result in moderate or minor injury if the warning is ignored.

CAUTION**Type and source of danger!**

Consequences of non-compliance.

Measures for avoiding the danger.

-
- ⚠ This is what a warning looks like for a hazard that could result in environmental damage if ignored.

NOTICE**Type and source of danger!**

Consequences of non-compliance.

Measures for avoiding the danger.


-
- ⚠ This is what a warning looks like for a hazard that could result in property damage if ignored.

3 Working basis

3.1 Order of the adjustments



Order

The setting positions for the machine are interdependent. Always comply with the order of individual adjustment steps as specified. It is absolutely essential that you follow all notices regarding prerequisites and subsequent settings that are marked with  in the margin.

NOTICE

Property damage may occur!

Risk of machine damage from incorrect order.

It is essential to follow the working order specified in these instructions.

3.2 Laying the cables

NOTICE

Property damage may occur!

Excess cables can impair the functioning of moving machine parts. This impairs the sewing function and can result in damage.

Lay excess cables as described.



To lay the cables:

1. Lay any excess cables neatly in proper cable snakes.
2. Bind together the cable loops with cable ties.



Important

Tie loops wherever possible to fixed parts. The cables must be secured firmly.

3. Cut off any overlapping cable ties.

3.3 Disassembling and assembling covers

WARNING



Risk of injury from moving parts!

Crushing possible.

Switch off the machine before removing or re-assembling covers.

For many types of adjustment work, you will have to remove the machine covers first in order to access the components.

This chapter describes how to remove and then assemble the individual covers again. The text for each type of adjustment work then specifies only the cover that needs to be removed at that particular time.

3.3.1 Swiveling the machine head up and down

NOTICE

Property damage may occur!

Risk of machine damage from falling machine head.


When swiveling down the machine head, hold the machine head in place until it has returned to its position.



Cover

To access the components on the underside of the machine, swivel up the machine head.

Fig. 1: Swiveling the machine head up and down



Swiveling up the machine head



Important

The transport carriage must be at the rear.



To swivel up the machine head:

1. Release the locking lever (3) under the tabletop.
2. Lift the machine head in the head cover area (1) and swivel up carefully.
3. The latch (2) latches into place.
The space under the stand is now accessible.

Swiveling down the machine head




To swivel down the machine head:

1. Hold the machine head in the head cover area (1).
2. Release the latch (2).
3. Swivel down the machine head carefully.
4. Latch the locking lever (3) under the tabletop.

3.3.2 Disassembling and assembling the arm cover

Fig. 2: Disassembling and assembling the arm cover



- (1) - Motor cover
- (2) - Screws
- (3) - Countersunk screw

- (4) - Arm cover
- (5) - Hand crank

Disassembling the arm cover



To disassemble the arm cover:

1. Unscrew the motor cover (1).
2. Loosen screws (2) and countersunk screw (3).
3. Disassemble the arm cover (4).

Assembling the arm cover



To assemble the arm cover:

1. Assemble the arm cover (4).
2. Tighten the countersunk screw (3).
3. Tighten the screws (2).
4. Press down the hand crank (5) and check for ease of movement. If necessary, adjust the arm cover position.
- ⚠ The hand crank (5) must disengage.
5. Tighten the screws for the motor cover (1).

3.3.3 Disassembling and assembling the head cover

Fig. 3: Disassembling and assembling the head cover



(1) - Screws

(2) - Head cover

Disassembling the head cover



To disassemble the head cover:

1. Loosen the screws (1).
2. Disassemble the head cover (2).

Assembling the head cover




To assemble the head cover:

1. Assemble the head cover (2).
2. Tighten the screws (1).

3.3.4 Removing and placing the rear cover

Fig. 4: Removing and placing the rear cover



(1) - Screws

(2) - Rear cover

Removing the rear cover



To remove the rear cover:

1. Loosen the screws (1).
2. Remove the rear cover (2).

Placing the rear cover




To place the rear cover:

1. Place the rear cover (2).
2. Tighten the screws (1).

3.3.5 Removing and placing the toothed belt cover

Fig. 5: Removing and placing the toothed belt cover



(1) - Screws

(2) - Toothed belt cover

Removing the toothed belt cover



To remove the toothed belt cover:

1. Loosen the screws (1).
2. Remove toothed belt cover (2).

Placing the toothed belt cover



To place the toothed belt cover:

1. Place the toothed belt cover (2).
2. Tighten the screws (1).

3.3.6 Opening and closing the hook cover

Opening the hook cover



To open the hook cover:

1. Switch on the machine and reference it.
 2. Remove the sewing material holder.
 3. Press the **Einfädelmodus (Threading mode)** button.
- ↳ The hook cover swivels to the side.

Closing the hook cover




To close the hook cover:

1. Release the **Einfädelmodus (Threading mode)** button.
- ↳ The hook cover swivels back.
2. Place the sewing material holder.

3.4 Flats on shafts

Some shafts have flat surfaces at the points where the components are clamped onto the shafts. This stabilizes the connection and makes adjusting easier.

Fig. 6: Flats on shafts



(1) - Flat

(2) - Shaft




Important

Always ensure that the screws are completely flush with the surface. If several screws are needed, make sure the first screw is placed in the direction of rotation on the flat of the shaft.

3.5 Aligning the machine head

Fig. 7: Aligning the machine head (1)



(1) - Base plate
(2) - Tabletop

(3) - Flat material



Proper setting

The upper side of the base plate (1) is level with the cutout in the tabletop (2). Height **X** of the transport system is identical on the left and the right both at the rear and the front position of the carriage. Check the height using the flat material (3).



To align the machine head:



1. Remove the sliding plate.
2. Check the position of the machine head using the flat material (3).
3. Swivel up the machine head ( p. 14).
4. Set the height.

Fig. 8: Aligning the machine head (2)

Carriage at rear position




Carriage at front position



5. Check the position of the machine head again.

- Front
- Carriage at rear position
- Carriage at front position

Fig. 9: Aligning the machine head (3)



(4) - Screws

(5) - Nuts

(6) - Screws

(7) - Block




6. Loosen the nuts (5).
7. Swivel down the machine head and lock it in place.
8. Use screws (4) to correct the height of the machine head at the front:
 - higher = turn counterclockwise
 - lower = turn clockwise
9. To adjust the locking mechanism, loosen the screws (6).
10. Move the block (7) up or down.
 - To slacken the locking mechanism: Slide the block up
 - To tighten the locking mechanism: Slide the block down
11. To test the setting, lock the machine head and check the play.

**Proper setting**

The locking mechanism is set correctly if the machine head can be locked in place with ease while not showing any play at the front bearing when moved up and down.

Fig. 10: Aligning the machine head (4)



(8) - Screw on the right

(9) - Threaded pin on the right




12. Loosen the screws on the left (not shown) and on the right (8).
13. Use the threaded pins on the left (not shown) and on the right (9) to adjust the height of the machine head at the rear:
 - higher = turn clockwise
 - lower = turn counterclockwise
14. Test the height of the base plate using flat material (3) and adjust as necessary.
15. Check heights **X** and adjust as necessary.
16. Check locking mechanism and adjust as necessary.

3.6 Locking the machine in place

For some adjustments, the machine must be locked in place. To do this, the locking peg from the accessories is inserted into a slot on the arm shaft crank, blocking the arm shaft.

Fig. 11: Locking the machine in place (1)




(1) - Locking peg
(2) - Large arresting groove

(3) - Small arresting groove
(4) - Arm shaft crank

There are 2 securing positions:

- **Position 1:** Looping stroke position
 - 5 mm end in the large slot
 - Adjusting the loop stroke and needle bar height
- **Position 2:** Needle at top dead center
 - 3 mm end in the small slot
 - Checking the top dead center of the needle bar

Fig. 12: Locking the machine in place (2)



(1) - Large arresting groove

(2) - Locking peg

Locking the machine in place

To lock the machine in place:

1. Insert the locking peg (2) with the appropriate end into the slot (1).

Removing the lock

To remove the lock:

1. Pull the locking peg (2) out of the slot (1).

3.7 Putting the machine into position

For some settings, the machine must be put into a certain position, using the hand crank on the arm cover.

Fig. 13: Putting the machine into position



(1) - Hand crank



To set the machine into position:

1. Press down and turn the hand crank (1) until the machine is in the setting position.

4 Positioning the arm shaft crank

WARNING




Risk of injury from moving parts!

Crushing possible.

Switch off the machine before you check and set the position of the arm shaft crank.

Fig. 14: Positioning the arm shaft crank



(1) - Arm shaft crank

(2) - Threaded pins




Proper setting

The threaded pins (2) on the arm shaft crank (1) are seated completely on the flat.



To set the arm shaft crank:

1. Disassemble the arm cover ( p. 16).
2. Loosen the threaded pins (2).
3. Turn the arm shaft crank (1) such that the threaded pins (2) are seated completely on the flat of the arm shaft.
4. Push the arm shaft crank (1) to the right as far as it will go.
5. Tighten the threaded pins (2) on the arm shaft crank (1).

5 Positioning the toothed belt wheels

WARNING



Risk of injury from moving parts!

Crushing possible.

Switch off the machine before you check and set the toothed belt wheels.



Proper setting

The two toothed belt wheels must be positioned relative to each other such that the toothed belt can run correctly.




Order

Always check the position of the other toothed belt wheel after making a change on either of the toothed belt wheels.

5.1 Adjusting the upper toothed belt wheel

Fig. 15: Adjusting the upper toothed belt wheel



(1) - Threaded pins
(2) - Flat of arm shaft

(3) - Upper toothed belt wheel
(4) - Toothed belt




Proper setting

The threaded pins for the upper toothed belt wheel are seated flush on the flat.




To adjust the upper toothed belt wheel:

1. Disassemble the arm cover ( p. 16).
2. Using the screwdriver, push the toothed belt (4) sufficiently far to the side so that the threaded pins (1) can be reached.
3. Loosen the threaded pins (1).

4. Turn the upper toothed belt wheel (3) such that the threaded pins (1) are seated flush on the flat (2) of the arm shaft.
5. Tighten the threaded pins (1).
6. Use the screwdriver to push the toothed belt (4) back again.

5.2 Adjusting the lower toothed belt wheel

Fig. 16: Adjusting the lower toothed belt wheel



(1) - Toothed belt
(2) - Snap ring

(3) - Lower toothed belt wheel
(4) - Threaded pins



Proper setting

The threaded pins for the lower toothed belt wheel are seated flush on the flat of the lower shaft.

The toothed belt runs correctly without running against the snap ring or slipping off.



To set the lower toothed belt wheel:

1. Loosen the threaded pins (4).
2. Turn the lower toothed belt wheel (3) such that the threaded pins (4) are seated on the flat of the arm shaft.
3. Move the lower toothed belt wheel (3) sufficiently far to the side so that the toothed belt (1) makes contact with the snap ring (2) without being pushed away.
4. Tighten the threaded pins (4).

6 Aligning the needle bar linkage

WARNING




Risk of injury from moving parts!

Crushing possible.

Switch off the machine before aligning the needle bar linkage sideways.

Fig. 17: Aligning the needle bar linkage



(1) - Threaded pin
(2) - Needle bar linkage

(3) - Needle hole



Proper setting

The needle enters the needle hole precisely in the center when the needle bar is at the bottom dead center.



To align the needle bar linkage:

1. Disassemble the head cover (📖 p. 17).
2. Loosen the threaded pins (1).
3. Set the needle bar linkage (2) so that the needle enters the needle hole (3) precisely in the center.
4. Tighten the threaded pins (1).

7 Position of the hook and needle

WARNING



Risk of injury from sharp parts!

Puncture possible.

Switch off the machine before adjusting the hook settings.

WARNING



Risk of injury from moving parts!

Crushing possible.

Switch off the machine before adjusting the hook settings.


7.1 Adjusting the looping stroke position



Information

The **looping stroke** is the path length from the bottom dead center of the needle bar up to the height where the hook tip picks up the loop of thread.

Fig. 18: Adjusting the looping stroke position (1)



(1) - Needle
(2) - Groove

(3) - Hook tip



Order

First, check the following settings:

- Aligning the needle bar linkage (📖 p. 30)




Proper setting

The machine is locked in place at position 1 (📖 p. 25).

- ✎ The hook tip (3) is precisely at the center of the needle (1).
The looping stroke is precisely 2 mm.

Fig. 19: Adjusting the looping stroke position (2)



(4) - Threaded pins
(5) - Set collar

(6) - Groove
(7) - Hook tip



To adjust the looping stroke position:

1. Lock the machine in place at position 1 (📖 p. 25).
2. Swivel up the machine head (📖 p. 14).
3. Loosen the threaded pins (4) on the set collar (5).
4. Rotate the hook such that the hook tip (7) is precisely at the center of the groove (6).
5. Tighten the threaded pins (4).
6. Remove the lock (📖 p. 25).



Order

Then check the following settings:


- Adjusting the needle guard (📖 p. 35)
- Setting the timing of cutting by the thread trimmer (📖 p. 66)

7.2 Adjusting the needle bar height



Order

First, check the following settings:

- Adjusting the looping stroke position ( p. 31)




Proper setting

The machine is locked in place at position 1 ( p. 25).

✎ The hook tip is level with the lower third of the groove on the needle.

Fig. 20: Adjusting the needle bar height





(1) - Needle bar
(2) - Screw

(3) - Hook tip
(4) - Groove




To adjust the needle bar height:

1. Disassemble the head cover ( p. 17).
2. Lock the machine in place at position 1 ( p. 25).
3. Loosen the screw (2).
4. Move the height of the needle bar (1) so that the hook tip (3) is in the middle of the lower third of the groove on the needle (4).



Important

When doing this, take care not to twist the needle.
The groove (4) must face toward the hook.

5. Tighten the screw (2).
6. Remove the lock ( p. 25).



Order

Then check the following setting:

- Adjusting the needle guard ( p. 35)

7.3 Adjusting the hook side clearance

NOTICE

Property damage may occur!

There is a risk of machine damage, needle breakage or damage to the thread if the distance between needle groove and hook tip is incorrect.

Check and, if necessary, readjust the distance to the hook tip after inserting a new needle with a different size.



Order

First, check the following settings:

- Aligning the needle bar linkage (📖 p. 30)
- Adjusting the looping stroke position (📖 p. 31)




Proper setting

The machine is locked in place at position 1 (📖 p. 25).

- ✎ The distance between the hook tip and the groove of the needle is no greater than 0.1 mm.

Fig. 21: Adjusting the hook side clearance







- (1) - Threaded pins
- (2) - Screws
- (3) - Hook support

- (4) - Hook tip
- (5) - Groove



To adjust the hook side clearance:

1. Lock the machine in place at position 1 ( p. 25).
2. Swivel up the machine head ( p. 14).
3. Loosen the screws (2).
4. Loosen the threaded pins (1).
5. Move the hook support (3) sideways such that the distance between the hook tip (4) and the groove of the needle (5) is no greater than 0.1 mm.
Ensure that the hook tip (4) does not touch the needle.
6. Tighten the screws (2).
7. Tighten the threaded pins (1).
8. Check the looping stroke position ( p. 31).
9. Remove the lock ( p. 25).



Order

Then check the following setting:

- Adjusting the needle guard ( p. 35)

7.4 Adjusting the needle guard

NOTICE

Property damage may occur!

There is a risk of machine damage, needle breakage or damage to the thread if the distance between needle groove and hook tip is incorrect.




Check and, if necessary, readjust the distance to the hook tip after inserting a new needle with a different size.

The needle guard prevents contact between needle and hook tip.



Order

First, check the following settings:

- Adjusting the looping stroke position ( p. 31)
- Adjusting the hook side clearance ( p. 34)
- Adjusting the needle bar height ( p. 33)




Proper setting

Machine is locked in place at position 1 ( p. 25).

- ↳ The needle guard pushes the needle away just enough so that it is not touched by the hook tip.

Fig. 22: Adjusting the needle guard



(1) - Needle guard
(2) - Screw

(3) - Needle



To adjust the needle guard:

1. Press down and turn the hand crank and check how far the needle guard (1) pushes the needle (3) away.
2. Turn the screw (2) such that the needle guard (1) just pushes the needle (3) far away enough so that it is not touched by the hook tip:
 - **for pushing away more:** Turn counterclockwise
 - **for pushing away less:** Turn clockwise

7.5 Adjusting the needle guide




Proper setting

Machine is locked in place at position 1 ( p. 25).

- ✎ The needle guard pushes the needle just enough away so that it cannot be touched by the hook tip.

Fig. 23: Adjusting the needle guide (1)



①

②

(1) - Needle guide


(2) - Screw



To adjust the needle guide:

1. To adjust the needle guide (1), turn the screw (2).
 - To move the needle guide closer to the needle: Turn screw (2) clockwise
 - To move the needle guide further away from the needle: Turn screw (2) counterclockwise

Fig. 24: Adjusting the needle guide (2)



2. Use a sheet of paper to check the distance between needle and needle guide (1) and adjust it if necessary.
3. The space between needle and needle guide (1) must just be wide enough to allow a sheet of paper to pass through.

8 Adjusting the bobbin case lifter

WARNING



Risk of injury from moving parts!

Crushing possible.

Switch off the machine before adjusting the settings on the bobbin case lifter.

Fig. 25: Adjusting the bobbin case lifter



(1) - Bobbin case lifter
(2) - Bobbin case

(3) - Bobbin case nose
(4) - Bobbin case support

The hook pulls the needle thread through between the nose of the bobbin case (3) and the bobbin case support (4).

The bobbin case lifter (1) now pushes the bobbin case (2) away so that a gap appears for the thread.

If the hook tip is located below the bobbin case lifter, the bobbin case lifter must open so that the thread can also slide past in that position.

So that the thread can slip through without a problem, the width of the lifting gap and the timing of opening have to be adjusted.

8.1 Adjusting the lifting gap



Order


Always check the width of the lifting gap after making changes to the needle thread size. The correct width of the lifting gap depends on the thickness of the needle thread.



Proper setting

The needle thread slides through unobstructed between the nose of the bobbin case and the bobbin case support.

Fig. 26: Adjusting the lifting gap




(1) - Threaded pin
(2) - Screw

(3) - Cover
(4) - Bobbin case lifter



To adjust the lifting gap:

1. Swivel up the machine head ( p. 14).
2. Loosen the screw (2).
3. Push the cover (3) downwards.
4. Loosen the threaded pin (1).
5. Set the bobbin case lifter (4) such that the gap between the nose of the bobbin case and the bobbin case support is just big enough to allow the needle thread to slip through without a problem.




Important

While doing so, ensure that the gap is not so big that the middle part of the hook swings back and forth, hitting the bobbin case support.

6. Tighten the threaded pin (1).
7. Push the cover (3) upwards.
8. Tighten the screw (2).

8.2 Adjusting the timing for opening

Fig. 27: Adjusting the timing for opening



(1) - Plug

(2) - Threaded pin



Proper setting

The bobbin case lifter starts to open exactly at the point when the hook tip is located below the bobbin case lifter after the loop is taken up.



To adjust the timing for opening:

1. Swivel up the machine head (📖 p. 14).
2. Remove the plug (1).
3. Press down and turn the hand crank until the tip of the needle is level with the throat plate.
- ⚡ The threaded pin (2) is accessible from the underside of the hook support.
4. Loosen the threaded pin (2) and use an allen key to turn it so that the allen key stands exactly vertical.
5. Tighten the threaded pin (2).
6. Insert the plug (1) into the opening.

9 Sewing foot lift

WARNING




Risk of injury from sharp and moving parts!

Puncture or crushing possible.

Switch off the machine before adjusting the settings of the sewing foot lift.

9.1 Adjusting the stroke position drive

Fig. 28: Adjusting the stroke position drive



(1) - Top edge of the stroke position housing
(2) - Toothed rack

(3) - Gear wheel
(4) - Threaded pins



Proper setting

The toothed rack must be 16.5 ± 0.5 mm distant from the top edge (1) of the stroke position housing. The threaded pins must be visible in the slotted hole and must be horizontal.




To adjust the stroke position drive:

1. Remove the motor cover.
2. Loosen the threaded pins (4).
3. Remove the gear wheel (3).
4. Move the toothed rack (2) to 16.5 mm below the upper stop.
5. Insert the gear wheel (3) so that the threaded pins (4) are horizontal.
6. Tighten the threaded pins (4).

9.2 Adjusting the light barrier

Fig. 29: Adjusting the light barrier



(1) - Mounting plate
(2) - Light barrier

(3) - Screw
(4) - Lever



Proper setting

The light barrier with its mounting plate must be installed so that the toothed rack triggers it before reaching the upper stop.

✎ The distance between the bottom edge of the mounting plate (1) and the stroke position housing is approx. 3.5 mm.




To adjust the light barrier:

1. Disassemble the head cover (📖 p. 17).
2. Loosen the screw (3).
3. Adjust the mounting plate (2).
4. Tighten the screw (3).
5. Switch off and on the machine again.



6. Press *Service*.
7. Input the password (25483).
8. Press *Multitest (Multi test) > Eingänge/Ausgänge testen (Test inputs/outputs)*.

9. Push the lever (4) up and monitor the display.
- ✎ It will show either +103 or -103.
-  10. Check that the toothed rack still has about 0.5 mm clearance from the stop.
11. If necessary, set the light barrier again using the mounting plate.

9.3 Adjusting the left stop screw



Proper setting

The left stop screw (3) of the lifting gear must be set so that the lever (1) performs no stroke when it is lying against the stop block (4). The levers of the lifting gear (5) overlap.



To adjust the left stop screw:




1. Switch off and on the machine again.
2. Reference the machine.
-  3. Press *Extras>Service>Multitest (Multi test)>Hublage einstellen (Set stroke position)*.
4. Press *Hüpfer/Drücker (Jumping foot/presser foot)* until the presser foot is selected.
-  5. Press down and turn the hand crank and check that no stroke is performed.

Fig. 30: Adjusting the left stop screw



- (1) - Lever
(2) - Nut
(3) - Stop screw


- (4) - Stop block
(5) - Lifting gear lever



6. Loosen the nut (2).
7. Turn the stop screw (3).
8. Tighten the nut (4).

9.4 Adjusting the sewing foot stroke relative to the needle bar stroke

Fig. 31: Adjusting the sewing foot stroke relative to the needle bar stroke



- (1) - Lever
- (2) - Lifting gear
- (3) - Eccentric

- (4) - Sewing foot stroke
- (5) - Stop screw
- (6) - Stop block



Proper setting

The lifting gear (2) must be switched on so that it performs a stroke. The stop block (6) must then lie against the right-hand stop screw (5). The eccentric (3) for the sewing foot stroke must be set so that

- the needle bar is at bottom dead center - the presser foot is lowered
- after the looping stroke - the presser foot stroke starts.



To set the sewing foot stroke relative to the needle bar stroke:

1. Switch off and on the machine again.
2. Reference the machine.
3. Press *Extras>Service>Multitest (Multi test)>Hublage einstellen (Set stroke position)*.
4. Press *Hüpfer/Drücker (Jumping foot/presser foot)* until the jumping foot is selected.
5. Switch on the sewing foot stroke in the control.





6. Turn the machine head to the looping stroke position.
- ↳ The lever (1) must make a movement.
7. Loosen both threaded pins on the eccentric (3).
8. Rotate the eccentric (3) on the arm shaft.
9. Tighten both threaded pins on the eccentric (3).
10. Turn the arm shaft and check that the lever (1) makes a movement.

9.5 Adjusting the sewing foot height

The sewing foot height can be set electronically from 1 mm to a maximum of 10 mm.



Proper setting

If a height of 1 mm is set in the control, the sewing foot must be 1 mm above the throat plate.



To adjust the height of the sewing foot:



1. Assemble the jumping foot.
2. Press *Extras* > *Service* > *Multitest (Multi test)* > *Hublage einstellen (Set stroke position)*.
3. Press *Hüpfer/Drücker (Jumping foot/presser foot)* until the jumping foot is selected.
4. Press *Nähfuß-Hub (Sewing foot stroke)*.
5. Enter a sewing foot height of 1.0 mm.
6. Move to position.



7. Turn the sewing foot to bottom dead center.
- ↳ The distance between the throat plate and sewing foot must be 1 mm.

Fig. 32: Adjusting the sewing foot height



- (1) - Nut
(2) - Screw

- (3) - Screw



8. Loosen the screw (3).

9. Turn the pivot shaft so that the distance between throat plate and sewing foot is 1 mm.
10. Tighten the screw (3).
11. Turn the sewing foot to top dead center.
- ✎ The distance between the throat plate and sewing foot must be 5 mm.
12. Loosen the nut (1).
13. Adjust the screw (2) so that the distance between the throat plate and sewing foot is 5 mm (corresponding to a 4 mm sewing foot stroke).




Information

The distance between min. and max. positions may have to be determined. If one of these settings is changed, the other setting must be checked again.

9.6 Adjusting the reference light barrier sewing axis

Fig. 33: Adjusting the reference light barrier sewing axis



(1) - Take-up lever disk

(2) - Threaded pin





Proper setting



The machine moves to the reference position with the needle bar at top dead center.



To adjust the reference light barrier:

1. Disassemble the arm cover ( p. 16).
2. Switch off and on the machine again.
3. Press *Multitest* (*Multi test*).
4. Input the password (25483).
5. Press *Multitest* (*Multi test*) > *Eingänge/Ausgänge testen* (*Test inputs/outputs*).
6. Lock the machine in place at position 2 ( p. 25).




7. Loosen the threaded pin (2).
8. Rotate the take-up lever disk (1) on the arm shaft.
 The switch S100 then switches.
9. Tighten the threaded pin (2).
10. Remove the lock ( p. 25).
11. Switch off and on the machine again.
12. Check that the needle bar is at top dead center.

10 Adjusting the needle thread tension

10.1 Adjusting the needle thread regulator

The needle thread regulator determines the tension applied to guide the needle thread around the hook. The required tension depends on the thickness of the sewing material, the thread strength, and the stitch length.

Fig. 34: Adjusting the needle thread regulator



(1) - Screw

(2) - Needle thread regulator



Proper setting

The loop of the needle thread slides at low tension over the thickest point of the hook, without forming loops or snagging.



To adjust the needle thread regulator:

1. Press down and turn the hand crank and monitor the progress of the needle thread around the hook.
2. Loosen the screw (1).
3. Move the needle thread regulator (2)
 - **more thread:** slide to the left
 - **less thread:** slide to the right
4. Tighten the screw (1).

10.2 Adjusting the thread tensioning spring

The thread tensioning spring holds the needle thread under tension from the top dead center of the thread lever up to the point when the needle eye plunges into the sewing material.



Proper setting


Initial position: The thread tensioning spring does not contact the stop until the needle eye has plunged into the sewing material.



Important

The adjustment for the thread tensioning spring must be varied according to the sewing material and the required sewing result.

Fig. 35: Adjusting the thread tensioning spring



(1) - Stop collar
(2) - Spring

(3) - Tension disk
(4) - Screw



To adjust the thread tensioning spring:

1. Loosen the screw (4).
2. **Adjusting the spring travel:** Turn the stop collar (1):
 - **Longer spring travel:** turn counterclockwise
 - **Shorter spring travel:** turn clockwise
3. **Adjusting the spring tension:** Turn the tension disk (3):
 - **Greater spring tension:** turn counterclockwise
 - **Lower spring tension:** turn clockwise




Important

Do not twist the stop collar in doing so.

4. Tighten the screw (4).

10.3 Calibrating the mechanical thread tension plate

Fig. 36: Calibrating the mechanical thread tension plate



(1) - Pretension

(2) - Thread tensioning spring

(3) - Main tension

(4) - Thread tension



Important

BEFORE calibrating the mechanical thread tension plate:
open the menu *Maschine (Machine) - Parameter (Parameters) - Konfiguration (Configuration) - Optionen (Options)*
and select *mechanische Fadenspannung (mechanical thread tension)*.

To calibrate the mechanical thread tension plate:

Adjusting the thread tension





1. Thread the needle thread 40/3 times **without** the thread tensioning spring (2).
2. Set the thread lever to the securing position and secure it ( p. 25).
3. Open the menu *Extras - Service - Multitest (Multi test)*.
4. Enter the password 25483.
5. Next, use *Eingänge/Ausgänge testen (Test inputs/outputs)* to select output 15.
6. Confirm with *OK*.
7. Switch on output 15.
- ↵ Main tension is open.
8. Select output 14.
9. Confirm with *OK*.
10. Switch on output 14.
- ↵ Pretension is open.

Fig. 37: Calibrating the mechanical thread tension plate




(5) - Spring balance



11. Hook the spring balance (5) (up to 1kg) into the needle thread and pull the needle thread off evenly and parallel to the tabletop.

✎ The value should be below approx. 100g - for the 911-211-10 with thread burner, the value should be as low as possible and barely allow for the thread to be guided in the thread tension (4).

Fig. 38: Calibrating the mechanical thread tension plate



(6) - Adjusting wheel

(7) - Adjusting wheel

(8) - Counternut



12. To adjust the thread tension, loosen the counternut (8) and turn the nut on the rear.

Increase the thread tension: turn clockwise

Reduce the thread tension: turn counterclockwise

13. To lock the tension, hold the nut in place and tighten the counternut (8) again.

Adjusting the pretension



14. Switch output 14 off again.

✎ The pretension is closed, while the main tension is still open.

15. Use the spring balance to check the thread tension again, which should be approx. 300g.

16. To adjust the thread tension, turn the adjusting wheel (6):
 Increase the thread tension: turn clockwise
 Reduce the thread tension: turn counterclockwise

Adjusting the main tension

17. Switch output 14 back on.
 ↳ The pretension is open again.
18. Switch output 15 off.
 ↳ The main tension is closed.
19. Use the spring balance to check the thread tension again, which should be approx. 400-500g.
20. To adjust the thread tension, turn the adjusting wheel (7):
 Increase the thread tension: turn clockwise
 Reduce the thread tension: turn counterclockwise




Information

To increase the main tension, it is possible to activate the pretension as well. In the DACCAD, switch off output 14 at the desired TP or enter a tension value over 50%.

10.4 Adjusting the electronical thread tension plate

Fig. 39: Adjusting the thread tension plate



- (1) - Tension disks
 (2) - Washer








- (3) - Nut
 (4) - Screw



To adjust the thread tension plate:


1. Pull the needle thread out of the thread tension.
2. Press *Extras > Service > Multitest (Multi test)*.
3. Input the password (25483).



4. Press *Fadenspannung* (Thread tension) > *Kalibrierung* (Calibration 3).
-  5. Loosen screw (4) and nut (3).
6. Loosen the washer (2).
7. Turn the washer (2) clockwise as far as it will go.
-  The tension disks lie flush on each other.
8. Use a (lead) pencil to mark 12 o'clock on the disk (2) and turn it approx. 15-30° clockwise.
-  9. Press *ESC* or *OK*.
10. Press *Kalibrierung 1* (Calibration 1).
-  11. Turn back the nut (3) until reaching the screw head of the screw (4).
12. Screw in the screw (4) until the nut (3) is positioned approx. 2 mm in front of the washer (2).
13. Loosen the screw (4) until the tension disks (1) tighten.
14. Using an open-jaw wrench, lightly tighten the nut (3) and slowly loosen the screw (4) until the tension disks (1) tighten.
-  15. Press *ESC*.
16. Press *Kalibrierung 3* (Calibration 3).
-  17. Hold the screw (4) still with a screwdriver, and tighten the nut (3). Take care that the washer (2) does not twist.
-  18. Press *ESC* and check that the tension disks (1) open easily.
19. Press *Kalibrierung 1* (Calibration 1) and check the closure of the tension disks.
20. Repeat the procedure for the 2nd thread tension.

10.5 Calibrating the electronical thread tension plate

Fig. 40: Calibrating the thread tension plate





To calibrate the thread tension plate:

1. Thread the needle thread 40/3 times and on to the thread lever (1).
2. With *Kalibrierung 1* (*Calibration 1*) selected, measure the thread tension with a thread scale (2).
3. Input the measured value into the control and confirm it with *OK*.
4. Perform the measurement and input also for *Kalibrierung 2* (*Calibration 2*) and *Kalibrierung 3* (*Calibration 3*).


Checking the calibration



1. Input the percentage value = 50 in the *Fadenspannung* (*Thread tension*) menu.
2. Press the *Ein* (*On*) button to switch on the tension.
3. Test the tension using a thread scale: Setpoint: 500 cN.
If necessary, other percentage values can be input.
4. If variations greater than $\pm 10\%$ are found: Set the thread tensions once again and repeat the calibration.
5. If the variations persist: Clean any dirt from the thread tensions including the magnets.

10.6 Calibrating the electromechanical thread tension plate

Fig. 41: Calibrating the electromechanical thread tension plate



- (1) - Mechanical thread tension
(2) - Thread tensioning spring

- (3) - Electronic thread tension
(4) - Mechanical pretension



Important

BEFORE calibrating the electromechanical thread tension plate: open the menu *Maschine* (*Machine*) - *Parameter* (*Parameters*) - *Konfiguration* (*Configuration*) - *Optionen* (*Options*) and select *mechanische Fadenspannung* (*mechanical thread tension*).


To calibrate the electronic thread tension plate:

Adjusting the pretension



1. Thread the needle thread **without** the thread tension spring (2).
2. Set the thread lever to the securing position and secure it (📖 p. 25).
3. Open the menu *Extras - Service - Multitest (Multi test)*.
4. Enter the password 25483.
5. Next, use *Eingänge/Ausgänge testen (Test inputs/outputs)* to select output 15.
6. Confirm with *OK*.
7. Switch on output 15.
- 👉 The mechanical thread tension (1) opens.
8. Check if the electronic (3) and the mechanical (1) thread tension are **open**.

Fig. 42: Calibrating the electromechanical thread tension plate




(5) - Spring balance



9. Hook the spring balance (5) (up to 1kg) into the needle thread and pull the needle thread off evenly and parallel to the tabletop.
- 👉 The value should be below approx. 100g - for the 911-211-10, the value should be as low as possible and barely allow for the thread to be guided in the pretension (4).

Fig. 43: Calibrating the electromechanical thread tension plate



- | | |
|---------------------------------|-----------------------|
| (1) - Mechanical thread tension | (6) - Counternut |
| (3) - Electronic thread tension | (7) - Adjusting wheel |



10. To adjust the thread tension, loosen the counternut (6) and turn the nut on the rear.

Increase the thread tension: turn clockwise

Reduce the thread tension: turn counterclockwise

11. To lock the tension, hold the nut in place and tighten the counternut (6) again.

Adjusting the mechanical thread tension



12. Switch output 15 off again.

☞ The mechanical thread tension (1) is closed, while the electronic thread tension (3) is still open.

13. Use the spring balance to check the thread tension again, which should be approx. 300g.

14. To adjust the thread tension, turn the adjusting wheel (7):

Increase the thread tension: turn clockwise

Reduce the thread tension: turn counterclockwise

15. Exit the menu *Eingänge/Ausgänge testen* (Test inputs/outputs).

☞ You have returned to the *Multitest* (Multi test) menu.

Adjusting the electronic thread tension

16. Open the *Multitest* (Multi test) menu and select the item *Fadenspannung* (Thread tension).



Important

Proceed quickly when adjusting these settings to keep the magnet from becoming too hot, resulting in incorrect values. If necessary, switch off the electronic thread tension and allow the magnets to cool down.




Information

The following settings require that you enter the measured thread tension and confirm it with a press of the **OK** button.

Fig. 44: Calibrating the electromechanical thread tension plate


Values of the
thread tension



17. Select value 3.

✚ The electronic thread tension is closed.

Fig. 45: Calibrating the electromechanical thread tension plate



(8) - Threaded pin

(9) - Threaded bush



18. Loosen the threaded pin (8) in the electronic thread tension.

19. Turn the threaded pin (9) clockwise while checking the thread tension repeatedly using the spring balance.

✚ The thread tension will increase initially before dropping again - it should settle at approx. 1,000g.

20. Tighten the threaded pin (8) of the electronic thread tension again.

21. Wait for a moment to allow the magnet to cool down.
22. Select value 3 again.
23. Check the thread tension using the spring balance.
24. Enter the value you measured and confirm by pressing *OK*.
25. Select value 2.
26. Check the thread tension using the spring balance.
27. Enter the value you measured and confirm by pressing *OK*.
28. Select value 1.
29. Check the thread tension using the spring balance.
30. Enter the value you measured and confirm by pressing *OK*.
31. To check the three values, press the button at the top right and set the percentage to 50.
32. Confirm the entry with *OK*.
 - ↳ The value shown at the top right now reads 50%.
33. Press the *Ein (On)* button.
 - ↳ The magnet is switched on.
34. Use the spring balance to check the thread tension - the value should be at approx. 500g.

35. Check additional values if necessary:
 - approx. 300g at 30%
 - approx. 800g at 80%
36. If the deviations in the values are too great, perform another calibration.

11 Short thread cutter (KFA)

WARNING



Risk of injury from sharp and moving parts!

Puncture or crushing possible.

Switch off the machine before adjusting the short thread cutter settings.

NOTICE

Property damage may occur!

Risk of breakage.

Never operate the machine without the thread-pulling knife.

The reverse-motion lock for the bobbin case is on the thread-pulling knife.




Information

For [videos](#) of KFA settings, visit our YouTube channel.

11.1 Adjusting thread-pulling knife and control cam

Fig. 46: Adjusting thread-pulling knife and control cam (1)



(1) - Thread-pulling knife
(2) - Counter blade

(3) - Knife carrier

Thread-pulling knife height

The height of the thread-pulling knife is set at the factory using washers underneath the knife carrier (3).



Important

When changing the knives, make sure that you do not lose the washers.

Thread-pulling knife position


The thread-pulling knife (1) cannot be moved on the knife carrier (3). Therefore, you will not have to adjust the cutting pressure after replacing the thread-cutting knife (1).

In rest position, the thread-pulling knife (1) completely covers the cutting edge of the counter blade (2). This prevents the needle thread from being damaged.

The pivot range of the thread-pulling knife is 23°.

Control cam

Fig. 47: Adjusting thread-pulling knife and control cam (2)



(4) - Control cam

(5) - Set collar




Important

The control cam (5) must make contact with the stop on the set collar (4).

11.2 Adjusting the locking latch

Fig. 48: Adjusting the locking latch



(1) - Locking latch

(2) - Roller

(3) - Control cam

(4) - Nut

(5) - Threaded pin

(6) - Locking pin

**Proper setting**

Press down and turn the hand crank until the roller (2) is at the highest point of the control cam (3).

Press the roller (2) against the control cam (3).

- ✎ The locking latch (1) can be swung out without clamping, and the distance between the locking latch (1) and locking pin (6) is no greater than 0.1 mm.




To adjust the locking latch:

1. Loosen the nut (4).
2. Turn the threaded pin (5) and set the distance.
3. Tighten the nut (4).

11.3 Adjusting the thread-pulling knife

Fig. 49: Adjusting the thread-pulling knife



- (1) - Thread-pulling knife
(2) - Marking
(3) - Knife carrier
(4) - Casting
(5) - Set collar

- (6) - Control cam
(7) - Clamping screw
(8) - Threaded pin
(9) - Lever
(10) - Roller

**Proper setting**

When the thread-pulling knife (1) is at rest, the distance between the highest point of the control cam (6) and the roller (10) is 0.1 mm.

The control cam (6) makes contact with the set collar (5).

The marking (2) on the thread-pulling knife (1) is adjacent to the cutting edge of the counter blade.

The knife carrier (3) has no axial play, but can still run smoothly.





To adjust the thread-pulling knife:

1. Loosen the screws on the set collar (5).
2. Slide the set collar (5) up to the hook bearing.
3. Tighten the screws on the set collar (5).
4. Loosen the screws on the control cam (6).
5. Turn the lever (9) so that the threaded pin (8) on the body casting (4) strikes the hook support.
6. Set the distance between the roller (10) and the highest point of the control cam (6) to 0.1 mm.
7. Tighten the screws on the control cam (6).
8. Loosen the clamping screw (7) on the lever (9).
9. Turn the thread-pulling knife (1) until the marking on the cutting edge of the counter blade (2) is adjacent to it.
10. Tighten the clamping screw (7). Take care to ensure that there is no axial play.
11. Loosen the screws on the set collar (5) and push the set collar against the control cam (6) as far as it will go.
12. Tighten the screws on the set collar (5).
13. Check the looping stroke (p. 31).

11.4 Adjusting the counter blade

Fig. 50: Adjusting the counter blade



(1) - Thread-pulling knife
(2) - Roller

(3) - Control cam




Proper setting

The thread must be reliably cut using little pressure.
Any 2 threads with the greatest strength used for sewing can be neatly cut simultaneously.

Adjusting the cutting pressure

The shape of the thread-pulling knife automatically creates the required cutting pressure as soon as both cutting edges are on top of one another.

Fig. 51: Adjusting the cutting pressure



(1) - Counter blade
(2) - Marking

(3) - Thread-pulling knife
(4) - Screw




To adjust the cutting pressure:

1. Swing out the thread-pulling knife (3) until the marking (2) is next to the cutting edge of the counter blade (1).
2. Loosen the screw (4).
3. Turn the counter blade (1) against the thread-pulling knife (3).
4. Tighten the screw (4).

11.5 Adjusting the cutoff position

Fig. 52: Adjusting the cutoff position



(1) - Control cam

(2) - Threaded pins



Proper setting

The default is that the cutoff position is "thread lever at top dead center". When the machine is at the position "thread lever at top dead center", the control cam (1) is at its highest point.



To adjust the cutoff position:

1. Press down the hand crank and turn it to the position "thread lever at top dead center".
2. Loosen the threaded pins (2).
3. Turn the control cam (1) correspondingly.
4. Tighten the threaded pins (2).

12 Thread trimmer

WARNING




Risk of injury from sharp and moving parts!

Cutting and crushing possible.

Switch off the machine before adjusting the thread trimmer.

12.1 Adjusting the height of the thread-pulling knife

Fig. 53: Adjusting the height of the thread-pulling knife



- (1) - Counter blade
- (2) - Thread-pulling knife
- (3) - Hook bearing screw-on surface

- (4) - Knife carrier
- (5) - Screw
- A** - Distance

The height of the thread-pulling knife is factory-set so that the distance **A** between the upper edge of the knife carrier (4) and the hook bearing screw-on surface (3) is 10.7 ± 0.05 mm. Fine adjustment is made by means of washers between the knife carrier (4) and the thread-pulling knife (2).



Important

When changing the knives, make sure that you do not lose the washers.



Proper setting

The thread-pulling knife (2) pivots as closely as possible above the hook and is at the same height as the counter blade (1).




To adjust the height of the thread-pulling knife:

1. Open the hook cover.
2. Loosen the screw (5).
3. Remove the thread-pulling knife (2).
4. Place as many washers between thread-pulling knife (2) and knife carrier (4) as necessary to ensure that the upper edges of the counter blade (1) and thread-pulling knife (2) are at the same height.
5. Keep any non-required washers on the top side between the thread-pulling knife (2) and screw (5).
6. Tighten the thread-pulling knife (2) using the screw (5).

12.2 Adjusting the cutoff curve

Fig. 54: Adjusting the cutoff curve (1)



- (1) - Roller
(2) - Set collar
(3) - Threaded pins
(4) - Control cam
(5) - Threaded pins

- (6) - Widest extent
(7) - Actuating lever
(8) - Clamping screw
(9) - Solenoid



Proper setting

The control cam (4) makes direct contact with the set collar (2).
The distance between the widest extent (6) of the control cam (4) and the roller (1) is 0.1 mm at most.
In resting position, the circle mark on the cutting edge of the thread-pulling knife is exactly next to the tip of the counter blade.



To adjust the cutoff curve:

1. Open the hook cover.
2. Loosen the threaded pins (3) on the set collar (2).
3. Push the set collar (2) as far as it will go to the left.
4. Tighten the threaded pins (3) on the set collar (2).




Important

Screw the 4 threaded pins (3) tightly in place on the set collar (2) before you loosen the threaded pins (5). The set collar (2) and control cam (4) are both mutually used as a stop and must not be loosened at the same time.

5. Loosen the threaded pins (5).
6. Press the actuating lever (7) against the solenoid (9).
7. Turn the control cam (4) such that its widest extent (6) is at the top, next to the roller (1).
8. Move the control cam (4) such that the distance between its widest extent (6) and the roller (1) is 0.1 mm at most.
9. Tighten the threaded pins (5).
10. Loosen the clamping screw (8) on the actuating lever (7).

Fig. 55: Adjusting the cutoff curve (2)



(10) - Screw

(11) - Counter blade


(12) - Thread-pulling knife

(13) - Screw

(14) - Hook thread clamp


(15) - Screw



11. Turn the thread-pulling knife (12) so that the circle mark is exactly next to the tip of the counter blade (11).
12. Tighten the clamping screw (8) on the actuating lever (7) such that the actuating lever (7) has no axial play.
13. Loosen the threaded pins (3) on the set collar (2).
14. Push the set collar (2) to the right as far as it will go and against the control cam (4).
15. Check the looping stroke position ( p. 31).
16. Tighten the threaded pins (3) on the set collar (2).

12.3 Adjusting the cutting pressure

Fig. 56: Adjusting the cutting pressure



- | | |
|----------------------------|-------------------------|
| (1) - Screw | (4) - Screw |
| (2) - Counter blade | (5) - Hook thread clamp |
| (3) - Thread-pulling knife | (6) - Screw |

The shape of the thread-pulling knife automatically creates the required cutting pressure as soon as the thread-pulling knife and counter blade make contact.



Proper setting

In resting position, the hook thread clamp makes contact with the thread-pulling knife without any pressure being applied. Any 2 threads with the greatest strength used for sewing can be neatly cut simultaneously.



Disturbance

Disturbances caused by an incorrect setting:

- Increased knife wear when the pressure is too great
- Problems when sewing on if the clamping pressure is too high
- Problems in cutting the thread




To adjust the cutting pressure:

1. Open the hook cover.
2. Turn the crank until the thread-pulling knife (3) can be swung out by hand.
3. Loosen the screw (1).
4. Position the thread-pulling knife (3) so that the arrow mark is exactly next to the tip of the counter blade (2).
5. Turn the hook thread clamp (5) so that it rests against the thread-pulling knife (3).
6. Turn the counter blade (2) so that it rests against the thread-pulling knife (3).
7. Tighten the screw (1).
8. Check the position of the knife, as the counter blade can easily become warped when the screw is being tightened.

12.4 Adjusting point in time for cutting

Fig. 57: Adjusting point in time for cutting



- (1) - Roller
(2) - Set collar
(3) - Control cam

- (4) - Thread-pulling knife
(5) - Counter blade
(6) - Threaded pins



Proper setting

The threads are cut when the thread lever is at the top dead center (hand-wheel position 60°).




To adjust the point in time for cutting:

1. Open the hook cover.
2. Loosen the threaded pins (6).
3. Turn the crank until the thread-pulling knife (4) can be swung out by hand.
4. Swivel the thread-pulling knife (4) forward until the circle mark is exactly next to the tip of the counter blade (5).
5. Adjust the handwheel position to 60°.
6. Push the control cam (3) to the left as far as it will go and against the set collar (2).
7. Turn the control cam (3) such that the roller (1) runs up at the contour of control cam (3) and the widest extent of the control cam is at hand-wheel position 60° at the highest point.
8. Tighten the threaded pins (6).
9. Check adjustment:
 - Insert the thread into thread-pulling knife (4) and slowly turn the crank.
 - Check the handwheel position at which the thread is cut.
10. If necessary, repeat adjustment steps 1 – 7 until the cut takes place at 60°.

13 Changing the presser bar

13.1 Disassembling the presser bar

Fig. 58: Disassembling the presser bar (1)



- (1) - Bearing with gear wheel
(2) - Threaded pins
(3) - Drive


- (4) - Screws
(5) - Screw



To disassemble the presser bar:

1. Remove the motor cover.
2. Loosen the threaded pins (2) and pull the bearing with the gear wheel (1) out towards the front.
3. Disassemble the drive (3).
4. Loosen the screws (4) and remove the drive shaft.
5. Loosen the screw (5).

Fig. 59: Disassembling the presser bar (2)



(6) - Block
(7) - Screw
(8) - Clip


(9) - Presser bar
(10) - Sleeve



6. Position the clip (8) so that the screw (7) is accessible.
7. Loosen the screw (7) and disassemble the clip (8).
8. Pull the sleeve (10) out.
9. Pull the clamp (6) right up to the top and pull the presser bar (9) out upwards.

13.2 Assembling the presser bar

Fig. 60: Assembling the presser bar (1)



(1) - Block
(2) - Screw
(3) - Clip


(4) - Presser bar
(5) - Sleeve



To assemble the presser bar:

1. Insert the presser bar (4).
2. Push the block (1) downwards.
3. Insert the sleeve (5).
4. Place the clip (3) and tighten the screw (2).

Fig. 61: Assembling the presser bar (2)



(6) - Bearing with gear wheel
(7) - Threaded pins
(8) - Drive

(9) - Screws
(10) - Screw



5. Tighten the screw (10).
6. Place the drive shaft and tighten the screws (9).
7. Assemble the drive (8).
8. Slip on the bearing with gear wheel (6).
9. Tighten the threaded pins (7).



Order

After that, set the sewing foot height (📖 p. 45).

14 Checking the machine zero point

The machine zero point is factory-set to the correct value.

Fig. 62: Checking the machine zero point



(1) - Clamp with test bores
(2) - Center point bore

(3) - Test bore

Gage required: Clamp with test bores.



To check the machine zero point:

1. Press *Extras > Service > Multitest (Multi test)*.
2. Press *Transportklammer (Transport clamp)*.



3. Assemble the clamp with test bores (1).



4. Press *Referenzieren (Referencing)*.

↳ The machine moves to the reference position.

5. Press *Mittelpunkt (Center point)*.

↳ The machine moves to the center position. The center of the needle is positioned within the center point bore (2), and the tip of the needle can be lowered into the bore by turning the arm shaft crank.

6. Press *Test*.

↳ The machine moves to the test position. The center of the needle is positioned within the test bore (3), and the tip of the needle can be lowered into the bore by turning the arm shaft crank.

15 Changing the drives

WARNING



Risk of injury from sharp and moving parts!

Puncture or crushing possible.

Switch off the machine before changing the drives.

15.1 Changing the sewing motor


15.1.1 Disassembling the sewing motor



To disassemble the sewing motor:

1. Cut off the cable ties.
2. Disconnect the motor cable from the control.
3. Remove the toothed belt cover (📖 p. 19).

Fig. 63: Disassembling the sewing motor



- (1) - Toothed belt
(2) - Plate with motor
(3) - Screws

- (4) - Toothed belt wheel
(5) - Screws




4. Loosen the screws (5).
5. Remove the toothed belt (1).
6. Pull off the plate with the motor (2).

7. Remove the toothed belt wheel (4).
To do so, loosen the screw on the toothed belt wheel.
8. Loosen the screws (3).
9. Remove the motor from the plate (2).

15.1.2 Assembling the sewing motor

Fig. 64: Assembling the sewing motor



- (1) - Toothed belt
(2) - Plate with motor
(3) - Screws

- (4) - Toothed belt wheel
(5) - Screws




To assemble the sewing motor:

1. Screw the new motor onto the plate (2) using the screws (3).
2. Assemble the toothed belt wheel (4).
To do so, tighten the screw on the toothed belt wheel.
3. Insert the plate with the motor (2).
4. Slightly tighten the screws (5).
5. Place and tighten the toothed belt (1).
6. Tighten the screws (5).
7. Check if the toothed belt operates in parallel.
If necessary, set parallel operation at the toothed belt wheel.
8. Place the toothed belt cover (📖 p. 19).
9. Connect the motor plug with the control.

15.2 Changing the X drive

Fig. 65: Changing the X drive



- (1) - Plug
- (2) - Screws
- (3) - Motor with flange

- (4) - Toothed belt
- (5) - Screw

Disassembling the drive



To disassemble the drive:

1. Disconnect both plugs (1).
2. Loosen all four screws (2).
3. Pull off the motor and flange (3).

Assembling the drive



To assemble the drive:

1. Insert a new motor and flange (3) on to the toothed belt (4).
2. Insert all four screws (2) and tighten them loosely.
3. Tension the toothed belt (4) using the screw (5).




Information

The toothed belt tension is set to the optimum value when the belt oscillates at 384 Hz. Check the oscillation, for instance, using a device made by Contitech.

4. Tighten all four screws (2).
5. Connect the plug (1).

15.3 Changing the Y drive

Fig. 66: Changing the Y drive



- (1) - Plug
- (2) - Screws
- (3) - Screw
- (4) - Equipotential bonding

- (5) - Toothed belt
- (6) - Motor
- (7) - Flange

Disassembling the drive



To disassemble the drive:

1. Disconnect the plug (1).
2. Unscrew the equipotential bonding (4).
3. Loosen the screw (3) to release the toothed belt (5) tension.
4. Loosen all four screws (2).
5. Pull the motor (6) off the flange (7).
6. Pull off the toothed belt wheel.

Assembling the drive



To assemble the drive:

1. Place the toothed belt wheel onto the new motor.
2. Insert the motor (6) into the toothed belt (5) and onto the flange (7).
3. Insert all four screws (2) and tighten them loosely.
4. Tension the toothed belt (5) using the screw (3).



Information

The toothed belt tension is set to the optimum value when the belt oscillates at 185 Hz. Check the oscillation, for instance, using a device made by Contitech.


5. Tighten all four screws (2).
6. Connect the plug (1).

7. Tighten the equipotential bonding (4).

16 Checking the play between toothed rack and gear wheel

The play between the toothed rack and the gear wheel must be checked on both sides of the machine. Because the structure is similar on both sides, testing is described here for one side only as an example.

Fig. 67: Checking the play between toothed rack and gear wheel



(1) - Gear wheel
(2) - Toothed rack

(3) - Nut
(4) - Screw



Proper setting

There should be no play between the gear wheel (1) and toothed rack (2).



To check the play between toothed rack and gear wheel:

1. Loosen the screw (4).
 2. Turn the nut (3) so that there is no play.
 3. Tighten the screw (4).
 4. Check the play along the entire length.
- ↪ The carriage can be moved without excessive play or stiffness.

17 Adjusting the safety release clutch

WARNING



Risk of injury from moving parts!

Crushing possible.

Switch the machine to bobbin change mode before adjusting the safety release clutch.


The safety release clutch disengages in the event of the thread jamming, thus separating the upper from the lower shaft and preventing the hook from being misadjusted or damaged.

17.1 Engaging the safety release clutch



Proper setting

Fig. 68: Engaging the safety release clutch (1)



(1) - Threaded pins

(2) - Threaded pins

When the safety release clutch is engaged, threaded pins (1) and (2) are parallel to each other (figure above).

When the safety release clutch is disengaged, threaded pins (1) and (2) are not parallel to each other.




To engage the safety release clutch:

1. Activate bobbin change mode.
2. Clean the sewing area and the area around the hook.
3. Deactivate bobbin change mode.
4. Switch off the machine.

5. Slide the transport carriage to the rear left - use CAUTION with the needle and the clamp.
6. Remove the sliding plate.

Fig. 69: Engaging the safety release clutch (2)



(1) - Button
(2) - Pin

(3) - Hole

7. Press the button (1) and keep it pressed.
↳ The pin (2) extends.
8. Press and turn the hand crank until the pin (2) slides into the hole (3).
9. Continue to turn the hand crank until the safety release clutch engages with an audible click.
10. Release the button (1).
11. Reinsert the sliding plate.
12. Switch on the machine.

17.2 Adjusting the torque


NOTICE

Property damage may occur!

If you change the torque, it could be that the safety release clutch will not disengage although this would be required.
This could cause machine damage, e.g. in the event of the thread jamming.

Do NOT change the factory adjustment.
Make sure that the torque remains at 8 Nm.

Fig. 70: Adjusting the torque



(1) - Slot

(2) - Marking point

(3) - Screw



Proper setting

The machine is set at the factory such that the torque is 8 Nm when the marking point (2) is exactly above the slot (1) of the washer.



To adjust the torque:

1. Swivel up the machine head.
2. Loosen the screw (3).
3. Using a screw driver, turn the washer on the slot (1):
 - Increase force: turn in the + direction
 - Decrease force: turn in the - direction
4. Tighten the screw (3).

18 Programming

Fig. 71: Programming



(1) - Control panel OP7000

The control is operated via the control panel OP7000 (1) located on the right next to the machine head.

The screen is a touchscreen, i.e. the buttons are displayed on the screen rather than provided as physical buttons. Buttons or functions are activated by tapping the corresponding position on the monitor.

Activating a button/selecting an element:



To activate a button or select an element:

1. Press the corresponding button or element with your finger or a touch-screen pen.

18.1 Structure of the software

You can create and manage seam programs and sequences via software. During sewing, these programs are called up and processed stitch by stitch.



Information

Seam program:

A seam program consists of a seam contour with parameters defining the individual contour sections.

Up to 99 seam programs can be stored in the system.

Seam programs have a file suffix of *.fnp911* after the filename.

Seam sequence:

Up to 30 seam programs can be combined in any order to form a seam sequence.












Up to 20 seam sequences can be stored in the system.















Seam sequences have a file suffix of *.seq911* after the filename.

The software is also used to define general settings that apply to all programs. There are also technical menu items for testing and maintaining the machine.

18.2 Overview of the menu structure

The following table provides an overview of the menu structure and the function buttons on the start screen.

Menu items in popup menus				
Menu item	Function	Sub-items	Sub-items	Described on
Datei (File)	Open existing programs for sewing Create new programs and copy or delete existing programs.	Löschen (Delete)		 p. 123
		Kopieren (Copy)		 p. 122
		Öffnen (Open)		 p. 100
		Neu (New)	Nahtprogramm (Seam program)	 p. 107
			Nahtsequence (Seam sequence)	 p. 119
		Speichern unter (Save As)		 p. 121
Bearbeiten (Edit)	Define general settings for all programs or modify an existing program.	Maschinenparameter (Machine parameters)		 p. 124
		Sequenz (Sequence)		 p. 119
		Nahtprogramm (Seam program)	Parameter	 p. 113
			Konturanpassung (Contour adjustment)	 p. 111
			Konturtest (Contour test)	 p. 110

Menu items in popup menus				
Menu item	Function	Sub-items	Sub-items	Described on
Extras	Display options: full-screen and zoom	Vollbild ein/aus (Full screen on / off)		 p. 99
		Zoom ein/aus (Zoom on / off)		 p. 99
	Technician menu: Adjustments, system information and tests	Service	Einstellungen (Settings)	 p. 130
			System-Information (System information)	 p. 137
			Multitest (Multi test)	 p. 133
			Initialisierung und Update (Initialization and update)	 p. 138
			Hersteller (nur für DA-Personal (Manufacturer (for DA personnel only)))	
Korrektur (Correction)	Short-term sewing with other values	Fadenspannung (Thread tension)		 p. 101
		Nähdrehzahl (Speed)		 p. 102
Buttons on the start screen				
	Continue sewing the contour from a particular point		Reparatur-Modus (Repair mode)	 p. 104
	Allow for a manual bobbin change		Spulenwechsel (Bobbin change)	 p. 102
	Reset counter to a particular value		Zählerreset (Reset counter)	 p. 106

18.3 Starting the software

After it was switched on, the machine performs a reference run. After this, the start screen is shown for a few seconds.

Fig. 72: Starting the software (1)



Here you can select the user interface language or use *Service* to quickly access the *Multitest* (*Multi test*) menu.



Information

Both functions can also be selected later from within the program via the menu items *Extras > Service*.


(See chapters **Testing the functions of the machine** ☎📖 p. 133) and **Changing the language** (📖 p. 131).)

If you do not press any buttons, the software automatically switches to the start screen after a few seconds.

Start screen

The start screen is displayed during sewing. When the machine is started, the start screen is opened with the settings of the last sewing program used.

Fig. 73: Start screen



- | | |
|--|---|
| (1) - Title bar | (6) - Button for resetting the counter |
| (2) - Status bar | (7) - Button for bobbin change |
| (3) - Main window: Display of the seam contour | (8) - Button of the current sewing parameters |
| (4) - Program bar | (9) - Button for Repair mode |
| (5) - Menu bar: Popup menu | (10) - Display of time of day |

Structure of the start screen

• Title bar (1)

This shows the version of the machine on the start screen. It also contains information on the menu item currently selected in the various menus.

• Status bar (2)

On the start screen, the seam sequence currently open is displayed here, and the time of day (11) is displayed at the right. It also bar contains information on the currently selected step in the various menus.

• Main window (3)

The contour to be sewn is displayed here.

• Program bar (4)


The seam programs of the seam sequence currently open are displayed in this line. The program currently being executed is highlighted in black. You can use the arrow buttons (6) at the right side of the bar to navigate along the bar and display any additional programs that do not fit on the bar.

If a seam sequence is not currently open but rather only a single seam program, then this program fills the entire bar.

• Menu bar (5)

The bar at the bottom contains the popup menu. This allows you to access the various different menu items for creating and editing seam programs and for performing settings and tests on the machine. An arrow (1) next to a menu entry indicates that pressing the entry will display further sub-items.

Fig. 74: Menu bar



(1) - Popup arrows

• Button for resetting the counter (6)






This button can be used for resetting the counter for the sewn programs or sequences. The current counter value is displayed next to this button.

• Button for bobbin change (7)

This button is used to inform the system that a new bobbin has been inserted (e.g. after a color change). The hook thread capacity is displayed next to this button.

• Display of the current sewing parameters (8)

The current sewing parameters are displayed below the repair mode button:

-  - Seam pattern size
-  - Sewing speed
-  - Thread tension
-  - Stitch length
-  - Number of stitches / hook thread consumed



Information

You can use the buttons Speed, Thread tension and Stitch length to access the sewing parameters directly (📖 p. 113).

• Button for Repair mode (9)


The topmost button at the right side is used for switching the repair mode on and off. The current status (*Ein (On)/Aus (Off)*) is displayed next to the button.

18.4 General operation of the software

18.4.1 Entering a password

Depending on the setting (see chapter **Changing the password options** (📖 p. 130)) a password is only required for accessing the technical menus or must be entered every time the machine is started. Next, the password entry screen is displayed.

Fig. 75: Entering a password



(1) - Input field

(2) - Numeric buttons



To enter a password:

1. Use the numeric buttons (2) to enter the password.



Information

The default password on delivery is: 25483.

The password can be changed via the *Extras* menu (📖 p. 130).


You can delete incorrect entries via the **DEL** button.

2. Press the **OK** button.

👉 The previously selected menu item opens.


18.4.2 Closing windows

A number of different buttons can be used for closing the currently open window.

Button	Meaning
	At the upper right in the title bar of all windows: ↳ The program jumps back by one navigation level.
OK CR	In windows with data entry or selection fields: ↳ The window is closed and the entered or selected data is adopted.
DEL Abbruch (Cancel)	In windows with data entry or selection fields: ↳ The window is closed and the entered or selected data is discarded.

18.4.3 Display principles

Fig. 76: Display principles



(1) - Grayed-out: Deactivated element (2) - Dark background: Activated element

- The currently activated or selected element is highlighted with a dark background (2)
- Buttons that are not used in the current context are grayed out (1)

18.4.4 Scrolling the display

Fig. 77: Scrolling the display



(1) - Scrollbar

A scrollbar (1) is displayed on the right when a displayed image is larger than the screen height.



To scroll the display:

1. Drag the scrollbar (1) up or down.

18.4.5 Selecting options from a list

When selecting options, a distinction is made between round radio buttons and square check boxes.

Selection with radio buttons

Fig. 78: Selection with radio buttons



(1) - Radio buttons: Selected element

With round radio buttons only one of the displayed options can be selected.




To select options using radio buttons:

1. Press the desired option.
- ↳ The selected option (1) is marked with a dot.

Selection with check boxes

Fig. 79: Selection with check boxes



(1) - Check box: Selected elements

Square check boxes allow for the selection of multiple entries.



To select options using check boxes:

1. Press the desired check box.
- ↳ The selected entries (1) are marked with a cross.

18.4.6 Using file filters

Fig. 80: File filter



When opening, copying or deleting seam programs a list of all available files is displayed.

You can use the filter functions to make the list more manageable:




To use file filters:

1. Press the **Dateifilter (File Filter)** button under the list.
 ↳ The file filter screen opens.
2. Press the desired filter criterion:
 - *.fnp911*: Seam programs only
 - *.seq911*: Seam sequences only
 - *All Files*: Seam programs and seam sequences
3. Press the **Öffnen (Open)** button.
 ↳ The list is updated according to the selected filter.

18.4.7 Entering text

A text entry window is displayed when text needs to be entered, e.g. for the name of a seam program.

Fig. 81: Entering text



Entering text



To enter text:

1. Use the keyboard (2) displayed to enter the text.

Switching between uppercase/lowercase



To switch between uppercase and lowercase:

1. Press the **Aa** (5) button.

Deleting the last character



To delete the last character:

1. Press the **DEL** (4) button.

Adopting the entered text




To adopt the entered text:

1. Press the **OK (CR)** (3) button.
- ➡ The entered text is adopted, and the text entry window is closed.

18.4.8 Entering parameter values

A numeric entry window opens when numeric values for program or machine parameters need to be entered.

Fig. 82: Entering parameter values



(1) - Title bar

(2) - Status bar

(3) - Symbol

(4) - Value range

(5) - Input field

(6) - Numeric buttons

The title bar (1) shows the parameter group.

The status bar (2) shows the name of the parameter currently being edited. The symbol (3) for the corresponding parameter is displayed below the parameter name.

The prescribed value range (4) for the parameter is displayed below the symbol (3).

The current valid value is displayed in the data entry field (5) below the value range (4).

Entering a value



To enter a value:

1. Press the desired value using the numeric buttons (6).

Deleting a value



To delete a value:

1. Press the **DEL** button.

Adopting a value




To adopt a value:

1. Press the **OK** button.
- ➡ The entered value is adopted, and the numeric entry window is closed.

18.4.9 Switching the full-screen display on and off

In order to see the seam contour in more detail you can switch the main window (1) to occupy the full screen and hide the buttons (2) on the right side of the start screen.

Fig. 83: Switching the full-screen display on and off



To switch full-screen on and off:


1. Press the menu items *Extras* > *Vollbild ein/aus* (Full-screen on / off).

↳ The display switches to the respective mode.

18.4.10 Switching zoom on and off

You can magnify the display in order to see the seam contour in more detail. There is only one zoom level that can be switched on or off.

Fig. 84: Switching zoom on and off



To switch zoom on and off:

1. Press the menu items *Extras* > *Zoom ein/aus* (Zoom on / off).

↳ The display switches to the respective mode.

18.5 Opening a seam program or seam sequence for sewing



To open a seam program or seam sequence for sewing:

1. Press the menu items *Datei* (*File*) > *Öffnen* (*Open*).

↳ The file selection screen is displayed.
All existing seam programs and seam sequences are displayed.



Information


You can use the *Dateifilter* (*File Filter*) to make the list more manageable ( p. 96).

Fig. 85: Opening a seam program or seam sequence for sewing



2. Press the desired file.

3. Press the **Öffnen (Open)** button.

↳ The seam program/seam sequence is opened on the start screen.



4. Press the pedal forwards.

↳ The seam program is sewn.

18.6 Briefly sewing with modified values

If you wish to briefly sew with a special material or use a particular thread strength with different values, without changing the seam program, you can use the *Korrektur* (*Correction*) menu item to temporarily change the values for thread tension and speed. The values then apply to all subsequently executed seams until the machine is switched off.



Important

If you wish to adopt the changes, you must modify and save the program. Otherwise, the values are automatically reset to the original settings when the machine is switched off.

18.6.1 Sewing with a modified thread tension



To sew with a modified thread tension:

1. Press the menu items *Korrektur* (*Correction*) > *Fadenspannung* (*Thread tension*).

➤ The window for changing the thread tension appears:

Fig. 86: Sewing with a modified thread tension



2. Enter the desired value.

3. Press the **OK** button.

➤ The value is adopted and used for all seams until the machine is switched off.

18.6.2 Sewing with a modified speed



To sew with a modified speed:

1. Press the menu items *Korrektur* (Correction) > *Nähdrehzahl* (Speed).

↳ The window for changing the thread tension appears:

Fig. 87: Sewing with a modified speed



2. Enter the desired speed.
3. Press the **OK** button.

↳ The value is adopted and used for all seams until the machine is switched off.

18.7 Changing the bobbin/managing a thread breaking

WARNING



Risk of injury from sharp and moving parts!

Puncture or crushing possible.


Switch the machine to threading mode before changing the bobbin.

The machine automatically detects when the hook thread has been used up and a new bobbin needs to be inserted.


In this case, or if thread breaking occurs, the *Fadenriss behandeln* (Manage Thread Breaking) window is automatically displayed.

18.7.1 Changing the bobbin

Fig. 88: Changing the bobbin



To change the bobbin:

1. Press the **Spulenwechsel (Bobbin change)** button.
 2. Change the bobbin ( p. 102).
 3. Use the *Vor* (*Forwards*) and *Zurück* (*Back*) buttons to move to the point where sewing is to continue.
 4. Press the **Weiternähen (Continue sewing)** button.
- ↳ The program jumps back to the start screen and sewing of the seam continues from the selected point.

18.7.2 Bobbin change without a request from the program




If you wish to independently insert a new bobbin without being requested to do so by the program, you have to press the **Spulenwechsel (Bobbin Change)** button on the start screen after changing the bobbin. This will inform the program that a new bobbin has been inserted, causing it to resume counting thread consumption starting with the full bobbin capacity.

18.7.3 Updating the bobbin capacity



To update the bobbin capacity:

1. Press the button **Spulenwechsel (Bobbin Change)**  on the start screen.
- ↳ The counter for the bobbin capacity begins anew with a full bobbin.

18.8 Continuing a seam after an error

18.8.1 Continuing a seam in Repair mode after an error

In Repair mode you can move to any desired point on the contour, e.g. in order to continue the seam program from this position after an error has occurred.



To continue a seam in Repair mode after an error:



1. Press the button **Reparaturmodus (Repair mode)**  on the start screen.
- ↳ The *Reparaturmodus (Repair mode)* window is displayed.

Fig. 89: Continuing a seam in Repair mode after an error



2. Use the **Vor (Forwards)** and **Zurück (Back)** buttons to move to the point where sewing is to continue.

OR

3. Use the buttons **Vor ++ (Forwards)** and **Zurück ++ (Back)** to skip to the beginning of the next or the beginning of the previous seam section.
4. Press the **Weiternähen (Continue sewing)** button.
- ↳ The program jumps back to the start screen and sewing of the seam continues from the selected point.

18.8.2 Continuing a seam after thread breaking

When the machine was set up, the needle thread monitor mode that is supposed to be active was selected in the machine parameters (MP 3 (📖 p. 127)).

In the event of an error, the machine will undo a certain number of preset stitches and stop.

The control panel will show the display *Fadenriss behandeln* (Manage Thread Breaking):

Fig. 90: Continuing a seam after thread breaking



Continuing a seam



To continue a seam after thread breaking:



1. Re-thread the needle thread.
2. Use the **Vor (Forwards)** and **Zurück (Back)** buttons to move to the point where sewing is to continue.



3. Continue sewing.

Canceling sewing and starting a new seam



To cancel sewing after thread breaking and start a new seam:



1. Press the **Abbruch (Cancel)** button.
2. Remove the transfer plate.
3. Press the pedal backwards.
 - ↳ The machine performs a reference run.
4. Press the pedal forwards.
 - ↳ The machine moves to the loading position, and you can start a new seam.

Checking or changing the bobbin



To change or check the bobbin:


1. Press the **Spulenwechsel (Bobbin change)** button.
- ↳ The display shows a prompt asking whether you wish to reset the bobbin counter.
2. Press the **JA (YES)** button if you wish to change the bobbin.
- ↳ The bobbin counter will be reset.

OR




3. Press the **NEIN (NO)** button if you merely wish to check the bobbin.
- ↳ The bobbin counter will not be reset.
4. Remove the transfer plate.
5. Press the **Einfädelmodus (Threading mode)** button on the machine head.
- ↳ The hook cover opens.
6. Change or check the bobbin.
7. Press the **Einfädelmodus (Threading mode)** button on the machine head.
- ↳ The hook cover closes.
8. Press the pedal forwards.
- ↳ The machine moves into the insertion position.
9. Insert the transfer plate.
10. Press the pedal or press the **Weiternähen (Continue Sewing)** button.
- ↳ The machine moves to the sewing position.
11. Press the pedal or press the **Weiternähen (Continue Sewing)** button.
- ↳ The sewing procedure is resumed.

18.9 Resetting the counter

Depending on the machine parameter settings, the counter counts the sewn programs or seam sequences up or down. You can use the *Zähler-Reset (Reset Counter)* button to reset the counter to the start value ( p. 129).



To reset the counter:

1. Press the button **Zähler-Reset (Reset Counter)**  on the start screen.
- ↳ The counter is reset to the value defined in the machine parameters.

18.10 Seam programs and seam sequences

18.10.1 Creating a new seam program

New seam programs are created using a Teach-In procedure. Individual seam paths with specific sewing parameters are defined via the control panel in order to do this.




To create a new seam program:

1. Press the menu items *Datei* (File) > *Neu* (New) > *Nahtprogramm* (Seam Program).

↳ The Teach-In window appears.

Fig. 91: Creating a new seam program



- (1) - Cursor position
- (2) - Cursor
- (3) - Arrow buttons
- (4) - OK button: Accept

- (5) - Save button
- (6) - Delete button
- (7) - Parameter button
- (8) - Line selection buttons

Defining the starting point



2. Define the starting point:

Method	Coordinate area
Using the arrow buttons (3) Caution For safety reasons, you cannot use the arrow buttons (3) to select a position beyond 90.1 or -92.6 on the Y-axis. Settings beyond these coordinates require that you use the pedal.	X -150 to X 230 Y 90.1 to Y -92.6
Using the pedal Every press of the pedal moves the cursor (2) by 0.1 in the direction of the selected axis (X or Y)	X -150 to X 230 Y 100 to Y -100
Entering coordinates directly via the cursor position (1)	X -150 to X 230 Y 100 to Y -100






3. Press the **OK** (4) button.

↳ The desired starting point is adopted and marked with a green / blue dot.

Selecting the line type




4. Use the line selection buttons (8) to select the type of line to be defined:

-  **Seamless path:** The clamp moves over this path to the next position without sewing
-  **Straight seam:** A straight path is sewn
-  **Curved seam:** A curve is sewn

↳ After pressing the button for a straight or curved seam, the corresponding window for entering the sewing parameters for this path opens.


Defining the sewing parameters for the path

Fig. 92: Defining the sewing parameters for the path








5. Press the desired parameter.

↳ The window for entering the parameter value opens.

6. Enter the desired value for the parameter ( p. 98).

Sewing parameters for Teach-In

Button	Meaning
	Speed
	Stitch length

Button	Meaning
	Thread tension
	Stroke height
	Thread cutting

Drawing a path



- Use the arrow buttons to move the cursor to the end point of the desired path.



Information

Alternatively, you can press an arrow button once in order to define the direction and then continue moving in this direction by pressing the pedal.



Important

Take care to ensure that the contour remains within the permissible sewing field of the machine.
Especially with curved paths, you should remember that the start and end points are not directly connected and that a curve is generated between these two points.

- Press the **OK** button.

↩ The seam path is adopted with the specified parameters.

Adding further seam paths

You can now define all further seam paths in the same manner.



- Begin every new seam path by selecting the type of line ( p. 108).

Deleting a seam path




- Press the **Löschen (Delete)** button.

↩ The last section of the seam path is deleted.

Saving a seam program


After you have defined all the seam paths, you can save the seam program and specify a name for the program.



1. Press the **Speich...(Save...)** button.
- ↳ The window for entering the name of the seam program opens.
2. Enter the desired name ( p. 97) and adopt the change by pressing **OK (CR)**.
- ↳ The seam program is now available under this name for sewing, editing or copying.



Important

Always perform a contour test after creating a new seam program ( p. 110).

NOTICE

Property damage may occur!

If you have entered contour points that lie outside the sewing field, the movement of the clamps during sewing can cause damage to the machine or the sewing material.

Always perform a contour test after creating or editing a contour to ensure that the entire contour lies within the permissible sewing field.

18.10.2 Performing a contour test


Perform a contour test every time after creating a new seam program or editing a seam contour to ensure that the contour you entered lies within the permissible sewing field.



To perform a contour test:

1. Press the menu items *Bearbeiten (Edit) > Nahtprogramm (Seam program) > Konturtest (Contour test)*.
- ↳ The *Konturtest (Contour test)* window appears.

Fig. 93: Performing a contour test



2. Move along the contour stitch by stitch using the **Vor (Forwards)** and **Zurück (Back)** buttons or the pedal.
3. Check that all points lie within the sewing field.

18.10.3 Editing a seam program

You can change the contour and the sewing parameters of existing seam programs. The changes are applied to the seam program that is currently open on the start screen.



To edit an existing seam program:

1. Open the seam program you wish to modify via the menu items *Datei (File) > Öffnen (Open)*.
- ↳ The seam program opens on the start screen.

Changing the contour of a seam program

NOTICE

Property damage may occur!

If you have entered contour points that lie outside the sewing field, the movement of the clamps during sewing can cause damage to the machine or the sewing material.


Always perform a contour test after creating or editing a contour to ensure that the entire contour lies within the permissible sewing field.



To change the contour of a seam program:

1. Press the menu items *Bearbeiten (Edit) > Nahtprogramm (Seam program) > Konturanpassung (Contour adjustment)*.
- ↳ The contour adjustment window appears:

Fig. 94: Changing the contour of a seam program (1)



(1) - Cursor

(2) - Scale: First to last stitch



2. Use the arrow buttons to move the cursor (1) to the position on the contour that is to be changed.



Information


You can also use the slider control on the scale (2) to select the stitching area you wish to change:

The first stitch of the seam pattern is at the top and the last stitch is at the bottom.

3. Press the **Go To** button.

- ↳ The selected contour region is displayed in detail.
The stitching point (2) to be modified is marked in red.

Fig. 95: Changing the contour of a seam program (2)



(3) - Old stitching point




(4) - New stitching point



4. Use the arrow buttons to move the stitching point to the new position (4).
- ↳ The modified seam path is displayed in green.
5. Press the **Weiter (Next)** button.
- ↳ The window for selecting the technology operations opens.


Fig. 96: Changing the contour of a seam program (3)



6. Select the desired technology operation(s) for the new seam path ( p. 94).
7. Confirm the selection with **OK**.
 You are returned to the detail window with the modified contour.
8. Press the **Weiter (Next)** button.
 A query dialog is displayed, asking if you wish to adopt the changes. Confirm the query dialog with **JA (YES)** to save the modified contour.



Important

Always perform a contour test after modifying a contour to ensure that the new seam path lies within the permissible sewing field ( p. 110).

Changing seam program parameters

You can change the general settings that apply to the entire seam program.



To change the seam program parameters:










1. Press the menu items *Bearbeiten (Edit) > Nahtprogram (Seam program) > Parameter (Parameters)*.
 The window for selecting the program parameter group appears:

Fig. 97: Changing seam program parameters













2. Press the desired parameter group.
↳ The individual parameters of this group are displayed.
3. Press the desired parameter.
↳ The window for modifying the parameter value opens.
4. Set the parameter to the desired value (📖 p. 98).




There are 8 program parameter groups:



Symbol	Parameter group
	PP1 - Configuration General settings
	PP2 - Load mode Load mode and position
	PP3 - Deposit mode Deposit mode and position
	PP4 - Soft start Number of stitches and speed
	PP5 - Needle thread monitor Sensitivity value for the needle thread monitor
	PP6 - Thread consumption Values for determining thread consumption
	PP7 - Move: Contour is moved in a particular direction
	PP8 - Scaling: The size of the contour is changed.






Overview of the individual program parameters




	PP1 - Configuration
Symbol	Meaning
	Seam name max. 20 characters
	Minimum sewing foot stroke height (min. = 1.0 .. max. = 10.0; Def. = 5.0 mm) Sets this as the minimum value of the programmable sewing foot stroke height so that only this value needs to be adjusted when sewing thicker materials.
	Adjust thread tension (min. = 10... max. = 200; Def. = 100 %) The thread tension profile for the entire contour is adjusted accordingly. A value of 100% means that no adjustments are made.
	Adjust empty-run speed (min. = 10... max. = 200; Def. = 100 %) The travel speeds are adjusted.
	Clamp ID code Barcode (ID code) of max. 10 characters for performing a safety check before the start of sewing (the barcode scanner additional equipment must be activated)



Symbol	Meaning
	Marking lamps Up to 4 marking lamps for easier alignment of the sewing material can be controlled (the additional equipment must be activated)
	Reversal mode The following options can be set: <ul style="list-style-type: none"> • Not activated: The needle remains at the Stop position • After the entire contour: After completing all seams in the contour, the needle is reversed to the value specified in the machine parameters • After each seam (Def.): The needle is reversed after every seam
	Needle cooling (On / Off) Activates/deactivates the needle cooling.
	Adjust sewing speed (min. = 10... max. = 200; Def. = 100%) The sewing speed is adjusted by the specified percent value.




	PP2 - Load mode
Symbol	Meaning
	Load mode The following options can be set: <ul style="list-style-type: none"> • Mode 1 (Def.) The clamp is opened in the loading position. The clamp is closed when the pedal is pressed. Pressing the pedal again starts the sewing of the seam. • Mode 2 The clamp is opened in the loading position. Pressing the pedal closes the left part of the two-piece clamp for angle mounting. Pressing the pedal again closes the right part. Another press of the pedal starts the sewing of the seam. • Mode 3 The clamp is opened in the loading position. Pressing the pedal closes the right part of the two-piece clamp for angle mounting. Pressing the pedal again closes the left part. Another press of the pedal starts the sewing of the seam. • Mode 4 Quick-start mode: The clamp is opened in the loading position. The clamp is closed, and the sewing of the seam is started when the pedal is pressed. With the alternating clamp, the seam is automatically started after insertion. This mode is only active when quick-start is activated in the machine parameters. The machine must be switched off and on in order to activate the quick-start mode. • Mode 5 The clamp remains closed in the loading position. Pressing the pedal again starts the sewing of the seam.
	Loading position (On / Off) With the loading position activated the clamps move to the desired position for convenient insertion of the sewing material.




Symbol	Meaning
	Loading position X The value range varies depending on the subclass and sewing field size.
	Loading position Y The value range varies depending on the subclass and sewing field size.






	PP3 - Deposit mode
Symbol	Meaning
	Deposit mode The following options can be set: <ul style="list-style-type: none"> • Mode 1 (Def.) Clamp is opened in the removal position. • Mode 2 The clamp remains closed in the removal position. The clamp is opened when the pedal is pressed. • Mode 3 The clamp remains closed in the removal position. Pressing the pedal opens the left part of the two-piece clamp for angle mounting. Pressing the pedal again opens the right part. • Mode 4 The clamp remains closed in the removal position. Pressing the pedal opens the right part of the two-piece clamp for angle mounting. Pressing the pedal again opens the left part. • Mode 5 Clamp remains closed in the removal position.
	Removal position (On / Off) With the removal position activated the clamps move to the desired position for convenient removal of the sewing material after the sewing procedure.
	Removal position X The value range varies depending on the subclass and sewing field size.
	Removal position Y The value range varies depending on the subclass and sewing field size.

	PP4 - Soft start
Symbol	Meaning
	Soft-start stitch count (min. = 0.. max. = 10; Def. 5)
	Soft-start speed (min. = 100 .. max. = 2000; Def. 300 rpm)

	PP5 - Needle thread monitor
	(min. = 0 .. max. = 99; Def. 5) Only active if activated in the machine parameters. (A higher value makes the needle monitor less sensitive. 99 = Needle thread monitor switched off in this program only.)

	PP6 - Thread consumption
Symbol	Meaning
	Sewing material thickness (min. = 0.. max. = 20.0; Def. 0) The thickness of the sewing material when pressed together.
	Adjust thread consumption (min. = -10.0.. max. = 10.0; Def. 0) Correction of the calculated values.

	PP7 - Move
Symbol	Meaning
	X move (min. = -5.0... max. = 5.0; Def. = 0.0 mm)
	Y move (min. = -5.0... max. = 5.0; Def. = 0.0 mm)

	PP8 - Scaling.
Symbol	Meaning
	X scaling (min. = 80... max. = 120; Def. = 100 %) 100% corresponds to the original size.
	Y scaling (min. = 80... max. = 120; Def. = 100 %)
	X scaling origin (min. = -150.0... max. = 150.0; Def. = 0.0 mm)
	Y scaling origin (min. = -150.0... max. = 150.0; Def. = 0.0 mm)

18.10.4 Creating a new seam sequence

You can combine up to 30 seam programs to form a seam sequence.
You can create up to 20 seam sequences in total.


Selecting seam programs



To select seam programs:



1. Press the menu items *Datei (File) > Neu (New) > Sequenz (Sequence)*.
- ↳ The window for selecting the seam program appears.

Fig. 98: Selecting seam programs



The existing seam programs are displayed at the right side of the screen. The field *Sequenz* (*Sequence*) field on the left shows the seam programs that have been transferred to the seam sequence.




2. Press the desired seam program.
 The selected seam program is highlighted with a dark background.
3. Press the **Einfügen (Insert)** button.
 The seam program is transferred to the seam sequence and is displayed in the *Sequenz* (*Sequence*) field on the left side of the screen.
4. Add further seam programs in the same manner.

Removing a seam program from a seam sequence






To remove a seam program from a seam sequence:

1. Press the seam program in the *Sequenz* (*Sequence*) field and then press the **Löschen (Delete)** button.
 The seam program is removed from the seam sequence.

Assigning a name to a seam sequence



To assign a name to a seam sequence:

1. Press the **Namen eingeben (Set name)** button.
 The window for entering the name of the seam sequence opens.
2. Enter the desired name and adopt the change by pressing **OK (CR)** ( p. 97).
 The seam sequence is now available under this name for sewing, editing or copying.

18.10.5 Editing a seam sequence

You can edit an existing seam sequence by adding or removing seam programs.



To edit a seam sequence:



1. Open the seam program you wish to modify via the menu items *Datei* (*File*) > *Öffnen* (*Open*).
 The seam sequence opens on the start screen.
2. Press the menu items *Bearbeiten* (*Edit*) > *Sequenz* (*Sequence*).
 The window for editing the seam sequence appears.

Fig. 99: Editing a seam sequence



- Use the buttons **Einfügen (Insert)** and **Löschen (Delete)** to add programs to the seam sequence or remove programs from the seam sequence.

18.10.6 Saving a seam program or seam sequence under a different name

You can also save existing seam programs or seam sequences under a different name.



Information

If you wish to create a new program that is similar to an existing program, you do not need to create the entire program anew. You can save the existing program under a new name and then change the details you wish to modify.




To save a seam program or a seam sequence under a different name:

- Press the menu items *Datei (File) > Speichern unter (Save As)*.
- A selection window allowing you to select a seam program or seam sequence appears.



Information

You can use the *Dateifilter (File Filter)* to make the list more manageable ( p. 96).

- Press the desired element.
- Press the **Speichern unter (Save As)** button.
- The window for entering the new name is opened.

4. Enter the desired name and adopt the change by pressing **OK** (CR) (📖 p. 97).
- ↳ The seam program or seam sequence is now available under this name for sewing, editing or copying.

18.10.7 Copying a seam program or seam sequence

You can also copy seam programs or seam sequences from a USB key to the control or from the control to a USB key.



Important

Not all commonly available USB keys are suitable for the copying process. You can obtain a suitable USB key from Dürkopp Adler.



To copy a seam program or a seam sequence:

1. Press the menu items *Datei* (File) > *Kopieren* (Copy).
- ↳ The window for selecting the file to be copied appears:

Fig. 100: Copying a seam program or seam sequence



- (1) - Select the source to be copied (2) - File selection window



2. Use the buttons (1) to select whether the data is to be copied from the DAC control or the USB key.
- ↳ The selected button is highlighted with a dark background. The files present at this location are listed in a selection window (2).



Information

You can use the *Dateifilter* (File Filter) to make the list more manageable (📖 p. 96).

3. Press the desired file.
- ↳ The selected file is highlighted with a dark background.

4. Press the **Datei kopieren (Copy File)** button.
- ↳ The selected file is copied to the USB key or the control.

18.10.8 Deleting a seam program or seam sequence


Seam programs or seam sequences that are no longer required can be deleted from the control.




To delete a seam program or a seam sequence:

1. Press the menu items *Datei (File)* > *Löschen (Delete)*.
- ↳ The window for selecting the file to be deleted appears:

Fig. 101: Deleting a seam program or seam sequence



Information

You can use the *Dateifilter (File Filter)* to make the list more manageable ( p. 96).



2. Press the desired file.
- ↳ The selected file is highlighted with a dark background.
3. Press the **Löschen (Delete)** button.
- ↳ The selected file is deleted.

18.11 Editing machine parameters

You use the machine parameters to define the basic machine settings. These basic settings apply to all programs.



To edit the machine parameters:







1. Press the menu items *Bearbeiten* (*Edit*) > *Maschinenparameter* (*Machine parameters*).
- ↳ The window for selecting the machine parameter group appears.

Fig. 102: Editing machine parameters












2. Press the desired parameter group.
- ↳ The individual parameters of this group are displayed.
3. Press the desired parameter.
- ↳ The window for modifying the parameter value opens.
4. Set the parameter to the desired value (📖 p. 98).

There are 6 machine parameter groups:

Symbol	Parameter group
	MP1 - Configuration General settings
	MP2 - Limit values Limit values for speeds and positions
	MP3 - Needle thread monitor Behavior after thread breaking
	MP4 - Thread cutting Speed, position and tension
	MP5 - Thread clamping Starting angle
	MP6 - Counters Settings for program and bobbin counters

Overview of the individual machine parameters

	MP1 - Configuration
Symbol	Meaning
	Needle cooling The following options can be set: <ul style="list-style-type: none"> • Without: No needle cooler activated. • Air cooling (Def.): The needle is cooled with air while sewing the seam • Ice cooling: Optional equipment
	Sewing foot mode The sewing foot can be operated in the following modes: <ul style="list-style-type: none"> • Jumping foot: The sewing foot only presses on the sewing material while the needle is in the sewing material • Presser foot: The sewing foot presses continuously on the sewing material
	Sewing field size Take care to ensure a valid sewing field size for your subclass when making the selection! (See chapter Technical data (p. 163)) <ul style="list-style-type: none"> • Normal sewing field (Def.): A sewing field of up to 200 x 300mm is available • Extra-large sewing field: A larger sewing field can be used in conjunction with the alternating clamps
	Optional equipment <ul style="list-style-type: none"> • Reduced clamp pressure: Optional equipment limiting the amount of clamp pressure to allow for better alignment on insertion. • Neat seam beginning: Optional equipment, activates stitch position optimization (Additional Instructions <i>Stitch Position Optimization</i>) • Marking lamps: Optional equipment providing orientation lines on insertion for easier alignment. Up to 4 marking lamps can be switched on for each program. This setting only activates the option, the actual switching is defined in the program parameters (see Marking lamps (p. 116)) • Barcode scanner: Optional equipment for performing a safety check before sewing. A barcode can be stored with each program. Agreement with the barcode on the clamp is checked. Sewing only proceeds when the barcodes agree. You enter the barcode ID in the program parameters (see Clamp ID code (p. 115)).
	Clamp type The following clamp types are available: <ul style="list-style-type: none"> • Single clamp: One-piece parallel clamp with angle mount • Single clamp with hanger (Def.): One-piece parallel clamp with hanger mount • Double clamp: Two-piece parallel clamp with angle mount • Alternating clamp: Removable clamp • Special clamp: Special clamp
	Clamp limitation <ul style="list-style-type: none"> • Preset limitation (Def.): No additional structures are taken into account • Special limitation: Individual limits are taken into account


Symbol	Meaning
	Pedal mode The following options are available: <ul style="list-style-type: none"> • Mode 1: The current position of the pedal is evaluated • Mode 2 (Def.): The pedal must be returned to the initial position after every actuation before a new actuation is recognized • Mode 3: The current position of the pedal is evaluated. The quick-start mode is also enabled (see Load mode (p. 116)). The machine must be switched off and on in order to activate the quick-start mode. • Push button: In push button mode one sensor is used only for controlling the clamp motion (up and down). The other sensor is used for starting the sewing process.
	Barcode mode The following options are available: <ul style="list-style-type: none"> • Manual: Machine checks whether the inserted clamp matches the entered seam program. If the clamp is correct, the machine is ready for sewing. If the clamp is incorrect, an error message will be displayed, and the clamp will have to be replaced. • Automatic: The machine looks for the seam program that matches the inserted clamp. The machine is ready for sewing once the seam program has been selected.










Information




The remaining thread monitor (MP 1, *Optionale Einrichtungen (Optional equipment)*) and the bobbin counter (MP 6) can be activated simultaneously. The display shows the two options as follows:



Fig. 103: Remaining thread monitor and bobbin counter












- (1) - Display - remaining thread monitor:
Remaining thread monitor active:
R shown
Remaining thread monitor inactive:
R hidden
- (2) - Display - bobbin counter:
Bobbin counter active: Number black
Bobbin counter inactive: Number grayed-out






	MP2 - Limit values
Symbol	Meaning
	Max. speed (min. = 500 .. max. = 2700; Def. 2700 rpm) All sewing programs are limited to this maximum speed
	Max. run-empty speed (min. = 10 .. max. = 100; Def. 100 %) Limits all clamp movements between the seams to this value
	Feed starting angle (min. = 30 .. max. = 350; Def. 210 degrees) The clamp motion during the stitch starts at this angle of needle motion
	Feed phase (min. = 30 .. max. 100; Def. 80 %) This parameter defines how the clamp is to be moved during the stitch. (A value of 100 % means that the desired clamp motion is distributed over the entire stitch.)
	Reversal position (min. = 0 .. max. 359; Def. 0 degrees) The needle is reversed at this angle in order to increase the clearance to the clamp.
	Edit times and routes This function is only for Dürkopp Adler Service personnel

	MP3 - Needle thread monitor
Symbol	Meaning
	Needle thread monitor mode The following options are available: <ul style="list-style-type: none"> • Threading position: After detection of a thread breaking, the thread is cut, and the clamp then moves to the threading position • Thread cutting (Def.): After detection of a thread breaking, the thread is cut, and the clamp then moves to the contour position according to the defined reversing path • Pausing: After detection of a thread breaking, seam motion is stopped • Not activated: The needle thread monitor is ignored
	Reversing path after thread breaking (min. = 0 .. max. 20; Def. 5 stitches) Number of stitches to be taken into account when reversing after a thread breaking

Symbol	Meaning
	Position of bobbin change X The value range varies depending on the subclass and sewing field size
	Position of bobbin change Y The value range varies depending on the subclass and sewing field size

	MP4 - Thread cutting
Symbol	Meaning
	Cutting speed (min. = 70 .. max. 500; Def. 180 rpm) Speed of the cutting stitch
	Cutting position on (min. = 0° .. max. 359°; Def. 180°) Angular position of the needle at which the thread cutting knife is switched on
	Cutting position off (min. = 0° .. max. 359°; Def. 359°) Angular position of the needle at which the thread cutting knife is switched off
	Thread tension during thread cutting (min. = 00 .. max. 100; Def. 10 %) Thread tension of the cutting stitch
	Position for thread tension during thread cutting (min. = 0° .. max. 400°; Def. 370°) Starting angle for the thread tension during the cutting stitch (At an angle greater than 359° the thread tension is activated in the next stitch.)

	MP5 - Thread clamping
Symbol	Meaning
	Close thread clamp at 1st stitch (min. = 0° .. max. 250°; Def. 180°) Start angle for closing the thread clamp during the first stitch
	Open thread clamp at 1st stitch (min. = 0° .. max. 359°; Def. 340°) Starting angle for opening the thread clamp during the first stitch. If the closing and opening angles are the same then the thread clamp is not activated


	MP6 - Counters
Symbol	Meaning
	Counter type The following options are available: <ul style="list-style-type: none"> • Increment counter (Def.): The counter is incremented after each sewn program • Decrement counter: The counter is decremented after each sewn program • Increment seam sequence counter: The counter is incremented after each seam sequence sewn • Decrement seam sequence counter: The counter is decremented after each seam sequence sewn
	Reset value for the counter (min. = 0 .. max. 9999; Def. 0) Value to which the counter is set when a counter reset is performed
	Adjust seam count for bobbin reserve (min. = 0 .. max. 100; Def. 0) A message is displayed to the user after the number of seams specified here have been sewn. A value of 0 deactivates the function
	Bobbin supply capacity (min. = 0.0 .. max. 400.0; Def. 0.0 m) A message is displayed to the user after the bobbin supply capacity has been consumed. A value of 0 deactivates the function



Information

The remaining thread monitor (MP 1, *Optionale Einrichtungen (Optional equipment)*) and the bobbin counter (MP 6) can be activated simultaneously. The display shows the two options as follows:

Fig. 104: Remaining thread monitor and bobbin counter




- | | |
|---|---|
| <p>(1) - Display - remaining thread monitor:</p> <p>Remaining thread monitor active:
 <i>R</i> shown
 Remaining thread monitor inactive:
 <i>R</i> hidden</p> | <p>(2) - Display - bobbin counter:</p> <p>Bobbin counter active: Number black
 Bobbin counter inactive: Number grayed-out</p> |
|---|---|

18.12 Checking and changing the technical settings

The technical settings are made via the menu item *Extras > Service*.

Fig. 105: Checking and changing the technical settings



Important

A password must always be entered in order to access the additional menu items in *Extras > Service* (📖 p. 92).

18.12.1 Changing the password options

The default password on delivery is: 25483.

You can change this password and also define whether the password only applies to the technical menu items or must always be entered after the machine is switched on.

Changing the password



To change the password:

1. Press the menu items *Extras > Service > Einstellungen* (*Settings*).
- ↳ The *Einstellungen* (*Settings*) window appears.
2. Press the *Operator Passwort* (*Password*) option.
3. In the following window press the option *Passwort ändern* (*Change password*).
- ↳ The window for entering the new password appears.
4. Enter the new password (📖 p. 92).



Important

The password must not have more than 5 digits.

5. Confirm the new password with **OK**.

Defining the password protected areas



To define the password protected areas:

1. Press the menu items *Extras* > *Service* > *Einstellungen* (*Settings*).
- ↳ The *Einstellungen* (*Settings*) window appears.
2. Press the *Operator Passwort* (*Password*) option.
- ↳ In the next window the *Aktivieren/De-aktivieren* (*Activate/Deactivate*) option indicates the type of password protection:
 - ☒ - Comprehensive password protection activated:
Password protection of the first action after switching on
 - ☐ - Comprehensive password protection deactivated:
Password protection for the technical menu items only
3. Press the *Aktivieren/De-aktivieren* (*Activate/Deactivate*) option to switch between each respective setting.
4. Confirm with **OK**.



Important

Switch off and on again the machine to adopt the setting.

18.12.2 Changing the language



To change the language:

1. In the menu item *Extras* > *Service* > *Einstellungen* (*Settings*) press the *Sprache* (*Language*) option.
- ↳ The list of available languages is displayed.
2. Press the desired language.
3. Confirm with **OK**.
- ↳ The screen is reloaded in the selected language.

18.12.3 Setting date and time



To set date and time:

1. In the menu item *Extras* > *Service* > *Einstellungen* (*Settings*) press the option *Datum* (*Date*) und (and) *Uhrzeit* (*Time*).
- ↳ The data entry window for date and time is displayed.
2. Enter the date and/or time.
3. Confirm with **OK**.
- ↳ The entered values are adopted.

18.12.4 Setting the brightness



To set the brightness:

1. In the menu item *Extras > Service > Einstellungen* (*Settings*) press the *Bedienfeld-Einstellungen* (*Control panel settings*) option.
2. In the following window press the *Kontrast* (*Contrast*) *Helligkeit* (*Brightness*) option.
 - ↳ A window with slider controls is displayed.
3. Pull the corresponding slider control up or down to change the value.
 - ↳ The changes are immediately visible on the display.

18.12.5 Testing the touchscreen

You can use the *Extras > Service > Einstellungen* (*Settings*) menu item to check that the touchscreen is functioning correctly over all areas of the screen.



To test the touchscreen:

1. In the menu item *Extras > Service > Einstellungen* (*Settings*) press the *Bedienfeld-Einstellungen* (*Control panel settings*) option.
2. In the following window press the *Touch Test* option.
 - ↳ An empty window is opened.
3. Use your finger to press various different points or draw lines.
 - ↳ When the touchscreen is functioning correctly all touched points of the screen are marked.


18.13 Testing the functions of the machine

You can use the *Extras > Service > Multitest (Multi test)* menu item to check the inputs and outputs, test the sewing motor and set the stroke position.

Fig. 106: Testing the functions of the machine



Information

The  *Transportklammer (Transport clamp)* function is only intended for use by Dürkopp Adler Service personnel.

18.13.1 Testing inputs and outputs

WARNING



Risk of injury from sharp and moving parts!

Puncture or crushing possible.

Do NOT reach into the machine during function testing of inputs and outputs.



Important

The instructions only provide an overview of the test possibilities.

The tests may only be performed by qualified specialists that have received training from Dürkopp Adler.




To test inputs and outputs:

1. In the menu item *Extras > Service > Multitest (Multi test)* press the *Eingänge / Ausgänge testen (Test inputs / outputs)* option.

➤ The *IO Test Seite (Page)* window is displayed.

Fig. 107: Testing inputs and outputs




(1) - Area for input elements


(2) - Area for output elements

The input elements are listed and selected at the left side (1) and the output elements at the right side (2).



2. For the 1st time: Press the button *ausgewählt: (selected:)* and select an output.
3. Next, use *Auswahl (Select) +* or *Auswahl (Select) -* to select the desired element in the respective area.
- ↳ The number of the element is displayed on the *ausgewählt: (selected:)* button.
4. Test the element using the *Ein/Aus (On/Off)* or *umschalten (switchover)* buttons, depending on the type of the input or output element.

	Input elements
No.	Meaning
S1	Lower right clamp
S2	Lower left clamp
S9	Needle thread monitor active
S10	Hook cover closed
S11	Machine head latch closed
S13	Pedal forwards
S14	Pedal backwards
S16	Pressure switch
S17	Quick-stop
S100	Sewing motor reference
S101	X-axis reference
S102	Y-axis reference
S103	Z-axis reference

	Output elements
No.	Meaning
Y1	Foot mode
Y2	Hook cover
Y3	Needle cooling on
Y4	Right clamp
Y5	Left clamp
Y8	Stitch position optimization
Y9	Threading switch lamp on
Y10	Oil level indicator warning light on
Y25	Marking lamp 1 (Z)
Y26	Marking lamp 2 (Z)
Y27	Marking lamp 3 (Z)
Y28	Marking lamp 4 (Z)

18.13.2 Adjusting the stroke position

WARNING



Risk of injury from sharp and moving parts!

Puncture or crushing possible.

Do not reach into the machine when setting the stroke position.



Switch off the power to the drives when you wish to test the freedom of motion of the sewing foot rod.





To adjust the stroke position:

1. In the menu item *Extras > Service > Multitest (Multitest)* press the *Hublage einstellen (Set stroke position)* option.

↪ The following options are displayed:

Symbol	Meaning
	Perform a reference run Check the movement
	Switch between jumping foot and presser foot Switch over the mode of operation

Symbol	Meaning
	Go to position Adjust the sewing foot height
	Switch off the power to the drives Manually check the freedom of motion of the sewing foot rod



2. Press the desired symbol and execute the function.

18.13.3 Testing the sewing motor

WARNING



Risk of injury from sharp and moving parts!

Puncture or crushing possible.

Do not reach into the machine during the function test of the motor.



To test the sewing motor:

1. In the menu item *Extras > Service > Multitest (Multi test)* press the *Nähmotor testen (Test sewing motor)* option.

↳ The sewing motor test screen is displayed:

Fig. 108: Testing the sewing motor








Important

Remove the thread from the needle and the thread lever before starting the test.



2. Press the  button.

↳ The window for entering the speed opens.

3. Enter the desired value (300 - 2000 rpm).
4. Press the  button.
 - ↳ The window for entering the cutting speed opens.
5. Enter the desired value (70 - 500 rpm).
6. Press the  button.
 - ↳ The sewing motor runs at the entered speed.
7. Press the  button.
 - ↳ The sewing motor stops.
8. Press the  button.
 - ↳ The sewing motor runs at the entered speed.
9. Press the  button.
 - ↳ The sewing motor stops, and the thread trimmer is actuated.

18.13.4 Calling up log displays and error lists


You can access the log settings and error lists via *Extras > Service > System-Information* (*System Information*).







To call up log displays and error lists:

1. Press the menu items *Extras > Service > System-Information* (*System Information*).
 - ↳ The selection screen for system information appears.

Fig. 109: Calling up log displays and error lists



2. Press the desired symbol.

Symbol	Meaning
	Control unit events List of the latest errors
	Log configuration Only for Dürkopp Adler Service personnel
	Log display List of the last log settings
	State of control panel Status appears in the log display

18.14 Initializing the control and performing updates


You can use *Extras > Service > Initialisierung (Initialization) and Update* to reset the control and control panel to the factory defaults and to update the control with a new software version.



To initialize the control and perform updates:

1. Press the menu items *Extras > Service > Initialisierung (Initialization) and Update*.
- The screen for initialization and update appears.

Fig. 110: Initializing the control and performing updates



18.14.1 Initializing the control



Important

Initializing the control resets all values to the factory default settings. All changes are lost. Only execute this option if you really want to return to the factory settings.



Order

Save your seam programs and seam sequences to a USB key before performing initialization.



1. Press the *Initialisierung (Initialize) Steuerung (Control)* option.

↳ The control is completely reset to the factory default settings.

18.14.2 Initializing the control panel



Important

Initializing the control panel resets all values to the factory default settings. All changes are lost. Only execute this option if you really want to return to the factory settings.



1. Press the *Initialisierung des Bedienfelds (Initialize control panel)* option.

↳ The control panel is completely reset to the factory default settings.

18.14.3 Performing an update of the control



Information

The latest software version is available in the download area at www.duerkopp-adler.com.

You can easily transfer a new software version from a USB key to the control.



Important

Not all commonly available USB keys are suitable for the copying process. You can obtain a suitable USB key from Dürkopp Adler.



To perform an update of the control:

1. Switch off the machine.
2. Insert the USB key into the USB port (1) on the control panel.

Fig. 111: Performing an update of the control



(1) - USB port



3. Switch on the machine.
↳ The software update is performed automatically.



Information

If the automatic update does not function then you can use the menu items *Extras > Service > Initialisierung (Initialize) and Update > Update der (the) Steuerung (control)* to load a specific software version.

Contact the Dürkopp Adler Service Hotline for this.

Displaying software version information

The menu item **?** displays information on the software currently installed on the machine.



To display information on the software version currently used:

1. Press menu items **?** > Press on *Info*.
↳ The following information is displayed:
 - Class
 - Subclass
 - Software version
 - Date of creation of this software version

18.15 DA CAD professional

You can use the DA-CAD professional program to create seam programs on a PC (*Operating Instructions DA CAD professional*).

19 Maintenance

WARNING



Risk of injury from sharp parts!

Punctures and cutting possible.

Prior to any maintenance work, switch off the machine or set the machine to threading mode.

WARNING




Risk of injury from moving parts!

Crushing possible.

Prior to any maintenance work, switch off the machine or set the machine to threading mode.

This chapter describes maintenance work that needs to be carried out on a regular basis to extend the service life of the machine and achieve the desired seam quality.

Advanced maintenance work may only be carried out by qualified specialists ( *Service Instructions*).

Maintenance intervals

Work to be carried out	Operating hours			
	8	40	160	500
Cleaning				
Removing sewing dust and thread residues	•			
Cleaning the motor fan mesh		•		
Lubricating				
Lubricating the machine head	•			
Lubricating the hook		•		
Servicing the pneumatic system				
Adjusting the operating pressure	•			
Draining the water condensation	•			
Cleaning the filter element		•		
Servicing specific components				
Checking the toothed belt		•		

19.1 Cleaning

WARNING



Risk of injury from flying particles!

Flying particles can enter the eyes, causing injury.

Wear safety goggles.

Hold the compressed air gun so that the particles do not fly close to people.

Make sure no particles fly into the oil pan.

NOTICE

Property damage from soiling!

Sewing dust and thread residues can impair the operation of the machine.

Clean the machine as described.

NOTICE

Property damage from solvent-based cleaners!


Solvent-based cleaners will damage paintwork.

Use only solvent-free substances for cleaning.

19.1.1 Cleaning the machine

Sewing dust and thread residues should be removed after every 8 operating hours using a compressed air gun or a brush. If very fluffy sewing material is being sewn, the machine must be cleaned more frequently.

Fig. 112: Cleaning the machine



Areas particularly susceptible to soiling:

- Knife on the winder (4)
- Area under the throat plate (3)
- Hook (2)
- Area around the needle (1)



To clean the machine:

1. Remove any dust and thread residues using a compressed air gun or a brush.

19.1.2 Cleaning the motor fan mesh

The motor fan mesh must be cleaned once a month using a compressed air gun. If very fluffy sewing material is being sewn, the motor fan mesh must be cleaned more frequently.

Fig. 113: Cleaning the motor fan mesh



To clean the motor fan mesh:

1. Remove any sewing dust and thread residues using a compressed air gun.

19.2 Lubricating

CAUTION



Risk of injury from contact with oil!

Oil can cause a rash if it comes into contact with skin.

Avoid skin contact with oil.

If oil has come into contact with your skin, wash the affected areas thoroughly.

NOTICE

Property damage from incorrect oil!

Incorrect oil types can result in damage to the machine.

Only use oil that complies with the data in the instructions.

CAUTION



Risk of environmental damage from oil!

Oil is a pollutant and must not enter the sewage system or the soil.

Carefully collect up used oil.

Dispose of used oil and oily machine parts in accordance with national regulations.

The machine is equipped with a central oil-wick lubrication system. The bearings are supplied from the oil reservoir.

For topping off the oil reservoir, use only lubricating oil **DA 10** or oil of equivalent quality with the following specifications:

- Viscosity at 40 °C: 10 mm²/s
- Flash point: 150 °C

You can order the lubricating oil from our sales offices using the following part numbers:

Container	Part no.
250 ml	9047 000011
1 l	9047 000012
2 l	9047 000013
5 l	9047 000014


19.2.1 Lubricating the machine head



Proper setting

The oil level is between the minimum level marking and the maximum level marking.

Fig. 114: Lubricating the machine head



(1) - Refill opening

(2) - Maximum level marking

(3) - Minimum level marking



To lubricate the machine head:

1. Check the oil level indicator every day.
2. If the oil level is below the minimum level marking (3):
Top off oil through the refill opening (1) but no higher than the maximum level marking (2).

19.2.2 Lubricating the hook


The approved oil quantity for hook lubrication is a factory specification.



Proper setting

1. Hold a piece of blotting paper next to the hook (1) while sewing.
- ✎ After sewing a stretch of approx. 1 m, the blotting paper will have been sprayed with a thin and even film of oil.

Fig. 115: Lubricating the hook



(1) - Hook

(2) - Screw



To lubricate the hook:

1. Turn the screw (2):
 - **more oil:** turn counterclockwise
 - **less oil:** turn clockwise



Important

The released amount of oil does not change until the operating time has run a few minutes. Sew for several minutes before you check the setting again.

19.3 Servicing the pneumatic system

19.3.1 Adjusting the operating pressure

NOTICE

Property damage from incorrect adjustment!

Incorrect operating pressure can result in damage to the machine.

Ensure that the machine is only used when the operating pressure is set correctly.




Proper setting

Refer to the **Technical Data** (📖 p. 163) chapter for the permissible operating pressure. The operating pressure cannot deviate by more than ± 0.5 bar.

Check the operating pressure on a daily basis.

Fig. 116: Adjusting the operating pressure



(1) - Pressure regulator

(2) - Pressure gage



To adjust the operating pressure:

1. Pull the pressure regulator (1) up.
2. Turn the pressure regulator until the pressure gage (2) indicates the proper setting:
 - Increase pressure = turn clockwise
 - Reduce pressure = turn counterclockwise
3. Push the pressure regulator (1) down.

19.3.2 Draining the water-oil mixture

NOTICE

Property damage from excess liquid!

Too much liquid can result in damage to the machine.

Drain liquid as required.

The collection tray (2) of the pressure regulator will show accumulation of a water-oil mixture.




Proper setting

The water-oil mixture must not rise up to the level of the filter element (1).

Check the level of the water-oil mixture in the collection tray (2).

Fig. 117: Draining the water-oil mixture



(1) - Filter element
(2) - Collection tray

(3) - Drain screw



To drain the water-oil mixture:

1. Disconnect the machine from the compressed air supply.
2. Place the vessel under the drain screw (3).
3. Loosen the drain screw (3) completely.
4. Allow the water-oil mixture to drain into the vessel.
5. Tighten the drain screw (3).
6. Connect the machine to the compressed air supply.

19.3.3 Cleaning the filter element


NOTICE

Damage to the paintwork from solvent-based cleaners!

Solvent-based cleaners damage the filter.

Use only solvent-free substances for washing out the filter tray.

Fig. 118: Cleaning the filter element




(1) - Filter element
(2) - Collection tray

(3) - Drain screw



To clean the filter element:

1. Disconnect the machine from the compressed air supply.
2. Drain the water-oil mixture ( p. 148).
3. Unscrew the collection tray (2).
4. Unscrew the filter element (1).
5. Blow out the filter element (1) using the compressed air gun.
6. Wash out the filter tray using benzine.
7. Tighten the filter element (1).
8. Tighten the collection tray (2).
9. Tighten the drain screw (3).
10. Connect the machine to the compressed air supply.

19.4 Servicing specific components

Checking the toothed belt

WARNING



Risk of injury from moving parts!

Crushing possible.

Switch off the machine before checking the condition of the toothed belt.

The condition of the toothed belt must be checked once a month.



Important

A damaged toothed belt must be replaced immediately.



Proper setting

The toothed belt exhibits no cracks or fragile areas.

When pressed with a finger, the toothed belt must yield no more than 10 mm.

19.5 Parts list

A parts list can be ordered from Dürkopp Adler. Or visit our website for further information at:

www.duerkopp-adler.com



20 Decommissioning

WARNING



Risk of injury from a lack of care!

Serious injuries may occur.

ONLY clean the machine when it is switched off.
Allow ONLY trained personnel to disconnect the machine.

CAUTION



Risk of injury from contact with oil!

Oil can cause a rash if it comes into contact with skin.

Avoid skin contact with oil.
If oil has come into contact with your skin, wash the affected areas thoroughly.



To decommission the machine:

1. Switch off the machine.
2. Unplug the power plug.
3. If applicable, disconnect the machine from the compressed air supply.
4. Remove residual oil from the oil pan using a cloth.
5. Cover the control panel to protect it from soiling.
6. Cover the control to protect it from soiling.
7. Cover the entire machine if possible to protect it from contamination and damage.

21 Disposal


CAUTION



Risk of environmental damage from improper disposal!

Improper disposal of the machine can result in serious environmental damage.

ALWAYS comply with the national regulations regarding disposal.



The machine must not be disposed of in the normal household waste.

The machine must be disposed of in a suitable manner in accordance with all applicable national regulations.

When disposing of the machine, be aware that it consists of a range of different materials (steel, plastic, electronic components, etc.). Follow the national regulations when disposing these materials.

22 Troubleshooting

22.1 Customer Service

Contact for repairs and issues with the machine:

Dürkopp Adler GmbH

Potsdamer Str. 190
33719 Bielefeld, Germany

Tel. +49 (0) 180 5 383 756

Fax +49 (0) 521 925 2594

Email: service@duerkopp-adler.com

Internet: www.duerkopp-adler.com



22.2 Messages of the software

Code	Description	Troubleshooting
Sewing motor		
1051	Sewing motor timeout <ul style="list-style-type: none"> • Cable to sewing motor reference switch defective • Reference switch defective • Machine head does not move freely or has excessive belt tension 	<ul style="list-style-type: none"> • Replace cable • Replace reference switch • Check the freedom of movement and belt tension of the machine head
1052	Sewing motor excess current <ul style="list-style-type: none"> • Sewing motor cable defective • Sewing motor defective • Control defective 	<ul style="list-style-type: none"> • Replace sewing motor cable • Replace sewing motor • Replace control
1053	Sewing motor mains voltage too high	Check the mains voltage
1055	Sewing motor overload <ul style="list-style-type: none"> • Sewing motor blocked/not moving freely • Sewing motor defective • Control defective 	<ul style="list-style-type: none"> • Remove blockage/sluggishness • Check the sewing motor • Check the control
1056	Sewing motor overtemperature <ul style="list-style-type: none"> • Sewing motor not moving freely • Sewing motor defective • Control defective 	<ul style="list-style-type: none"> • Eliminate seizing • Replace sewing motor • Replace control

Code	Description	Troubleshooting
1058 1302 1342 1344	Sewing motor speed • Sewing motor defective Sewing motor error Control not receiving pulses from pulse encoder in motor Sewing motor error Internal error	<ul style="list-style-type: none"> • Replace sewing motor • Check the cable from the pulse encoder in the motor to the control • Switch off and on the machine again • Software update
Stepper motors		
2101	X-axis stepper motor referencing timeout • Faulty reference switch setting • Cable to reference switch defective • Reference switch defective	<ul style="list-style-type: none"> • Align reference switch • Replace cable • Check reference switch
2102	X-axis stepper motor current error • Stepper motor blocked • Encoder cable not connected or defective • Encoder defective	<ul style="list-style-type: none"> • Fix blockage • Check/replace the encoder cable • Replace the stepper motor
2152	X-axis stepper motor excess current	<ul style="list-style-type: none"> • Replace the stepper motor • Replace control
2153	X-axis stepper motor overvoltage • Mains voltage too high	<ul style="list-style-type: none"> • Check mains voltage
2155	X-axis stepper motor overload • Feed system not moving freely • Obstacle to feed movement	<ul style="list-style-type: none"> • Eliminate sluggishness • Remove obstacles/adjust the motion
2156	X-axis stepper motor overtemperature • Stepper motor sluggish • Stepper motor faulty • Control defective	<ul style="list-style-type: none"> • Eliminate seizing • Replace the stepper motor • Replace control
2201	Y-axis stepper motor referencing timeout • Faulty reference switch setting • Cable to reference switch defective • Reference switch defective	<ul style="list-style-type: none"> • Align reference switch • Replace cable • Replace reference switch
2202	Y-axis stepper motor current error • Stepper motor blocked • Encoder cable not connected or defective • Encoder defective	<ul style="list-style-type: none"> • Fix blockage • Check/replace the encoder cable • Replace the encoder
2252	Y-axis stepper motor excess current	<ul style="list-style-type: none"> • Replace the stepper motor • Replace control
2253	Y-axis stepper motor overvoltage • Mains voltage too high	<ul style="list-style-type: none"> • Check mains voltage

Code	Description	Troubleshooting
2255	Y-axis stepper motor overload <ul style="list-style-type: none"> Feed system not moving freely Obstacles to the feed motion 	<ul style="list-style-type: none"> Eliminate sluggishness Remove obstacles/adjust the motion
2256	Y-axis stepper motor overtemperature <ul style="list-style-type: none"> Feed system not moving freely Stepper motor faulty Control defective 	<ul style="list-style-type: none"> Eliminate seizing Replace the stepper motor Replace control
2301	Stroke position stepper motor refer- encing timeout <ul style="list-style-type: none"> Faulty reference switch setting Cable to reference switch defective Reference switch defective 	<ul style="list-style-type: none"> Align reference switch Replace cable Replace reference switch
2302	Stroke position stepper motor current error <ul style="list-style-type: none"> Stepper motor blocked Encoder cable not connected or defective Encoder defective 	<ul style="list-style-type: none"> Fix blockage Check/replace the encoder cable Replace the encoder
2352	Stroke position stepper motor excess current	<ul style="list-style-type: none"> Replace the stepper motor Replace control
2353	Stroke position stepper motor overvoltage <ul style="list-style-type: none"> Mains voltage too high 	<ul style="list-style-type: none"> Check mains voltage
2355	Stroke position stepper motor overload <ul style="list-style-type: none"> Feed system not moving freely Obstacles to the feed motion 	<ul style="list-style-type: none"> Eliminate sluggishness Remove obstacles/adjust the motion
2356	Stroke position stepper motor over- temperature <ul style="list-style-type: none"> Feed system not moving freely Stepper motor faulty Control defective 	<ul style="list-style-type: none"> Eliminate sluggishness Replace the stepper motor Replace control
Machine control		
3100	Machine control voltage <ul style="list-style-type: none"> Temporary mains voltage interruption 	<ul style="list-style-type: none"> Check the mains voltage
3102	Machine voltage in sewing motor intermediate circuit <ul style="list-style-type: none"> Temporary mains voltage interruption 	<ul style="list-style-type: none"> Check the mains voltage
3103	Machine voltage in stepper motor intermediate circuit <ul style="list-style-type: none"> Temporary mains voltage interrup- tion 	<ul style="list-style-type: none"> Check the mains voltage
3107	Machine temperature <ul style="list-style-type: none"> Ventilation openings closed Ventilation grille dirty 	<ul style="list-style-type: none"> Clean ventilation grille Check ventilation openings
3109	Threading mode is switched on	Switch off threading mode
3121	Compressed air is missing, not sufficient	Turn up air pressure and stabilize

Code	Description	Troubleshooting
3123	Oil sensor active	Top off the oil
3210	Thread broken	Re-thread the thread
3215	Bobbin empty (remaining thread counter)	Insert full bobbin
3220	Bobbin empty (remaining thread counter)	Insert full bobbin
3500	Error in calculating the contour data	<ul style="list-style-type: none"> • Reload the contour data • Check the contour data
3501	Target position of the XY clamps outside the motion limits	Adjust the contour data
3502	Target position of the XY clamps within the "forbidden areas"	Adjust the contour data
3721 3722	Internal error	<ul style="list-style-type: none"> • Switch off and on the machine • Software update • Notify DA Service
4201	Internal CF card defective	<ul style="list-style-type: none"> • Switch off and on the machine • Retrofit/replace control
5301	Program cannot be sewn	Copy program to DAC
6551 6554 6651 6653 6751 6761	Error in machine head position/AD converter/process error Internal error	<ul style="list-style-type: none"> • Switch off and on the machine • Software update • Notify DA Service
6952	Stepper motor driver error Internal error	<ul style="list-style-type: none"> • Switch off and on the machine • Software update • Notify DA Service
Communication		
7801	Control panel interface communication <ul style="list-style-type: none"> • Cable disturbance • Cable 	<ul style="list-style-type: none"> • Switch off and on the machine • Software update • Notify DA Service
8151 8156 8159	IDMA error <ul style="list-style-type: none"> • Disturbance • Control defective 	<ul style="list-style-type: none"> • Switch off and on the machine • Replace control
8152 8154	IDMA error <ul style="list-style-type: none"> • Internal error 	<ul style="list-style-type: none"> • Switch off and on the machine • Software update • Notify DA Service
8252 8257 8258 8256 8254	ADSP Boot/Xilinx Boot/ Boot error Disturbance	<ul style="list-style-type: none"> • Switch off and on the machine

Code	Description	Troubleshooting
8351	Test pins error	<ul style="list-style-type: none"> • Switch off and on the machine • Software update • Notify DA Service
8400	Control panel has no valid program for the DAC.	Load the current program into the control panel from a USB key.
8401 8402	Control panel has no valid program for the DAC.	Load the current program into the control panel from a USB key.
8403	Program in DAC is no longer current.	Load the current program into the DAC.
8404 8407	DAC update was faulty.	<ul style="list-style-type: none"> • Attempt the update again • Check cable connection • Replace the DAC
8408	Waiting for a DAC reset.	Wait until the restart has been performed (Duration: several seconds).
8411	DAC program check is active.	Wait until the test has been performed (Duration: several seconds).
8414	DAC update succeeded.	
8801 8805 8806 8890 8891	Error in test pins/signal processing/ event processing/ Memory wrapper/ list functions Internal error	<ul style="list-style-type: none"> • Switch off and on the machine • Software update • Notify DA Service
System		
9000	Reference run active	
9002	Machine head not locked	Lock machine head
9006	Quick-stop switch is activated.	Releasing the quick-stop switch
9016	Wrong bar code ID	Change the program
9100	The counter has not reached the default value.	Press the OK button. The counter is reset.
9601	Stop while sewing on the contour Continue sewing?	<ul style="list-style-type: none"> • OK button = Continuing the sewing process • ESC button = Canceling the sewing process
9700	Bobbin case retainer for bobbin change not closed	Close the bobbin case retainer for bobbin change
9701	Parallel clamps not lowered	<ul style="list-style-type: none"> • Remove obstacles • Align sensors
9900	Incorrect machine parameters	Initialize the data
9901	Incorrect sequences	Initialize the data
9902	Incorrect program parameters	Initialize the data

22.3 Errors in sewing process

Error	Possible causes	Remedial action
Unthreading at seam beginning	Needle thread tension is too firm	Check needle thread tension
Thread breaking	Needle thread and hook thread have not been threaded correctly	Check threading path
	Needle is bent or sharp-edged	Replace needle
	Needle is not inserted correctly into the needle bar	Insert the needle correctly into the needle bar
	The thread used is unsuitable	Use recommended thread
	Thread tensions are too tight for the thread used	Check thread tensions
	Thread-guiding parts, such as thread tube, thread guide or thread take-up disk, are sharp-edged	Check threading path
	Throat plate, hook or spread have been damaged by the needle	Have parts reworked by qualified specialists
Skip stitches	Needle thread and hook thread have not been threaded correctly	Check threading path
	Needle is blunt or bent	Replace needle
	Needle is not inserted correctly into the needle bar	Insert the needle correctly into the needle bar
	The needle thickness used is unsuitable	Use recommended needle thickness
	The reel stand is assembled incorrectly	Check the assembly of the reel stand
	Thread tensions are too tight	Check thread tensions
	Throat plate, hook or spread have been damaged by the needle	Have parts reworked by qualified specialists

Error	Possible causes	Remedial action
Loose stitches	Thread tensions are not adjusted to the sewing material, the sewing material thickness or the thread used	Check thread tensions
	Needle thread and hook thread have not been threaded correctly	Check threading path
Needle breakage	Needle thickness is unsuitable for the sewing material or the thread	Use recommended needle thickness


23 Technical data

23.1 Data and characteristic values


Technical data	Unit	911-210-3020-10	911-210-6020-10	911-210-6055-10
Type of stitches		301		
Hook type		Vertical hook		
Number of needles		1		
Needle system		134/35		
Needle strength	[Nm]	80 - 180		
Thread strength	[Nm]	Needle thread 10/3 Hook thread 20/3		
Stitch length	[mm]	up to 12.7, dependent on seam pattern		
Speed maximum	[min ⁻¹]	2700 intermittent		2000 intermittent
Needle bar stroke	[mm]	40		
Clamp stroke	[mm]	20		
Sewing foot stroke	[mm]	20		
Sewing field size	[mm]	300 x 200	600 x 200	600 x 550
Number of free seam contours		99		
Mains voltage	[V]	230		
Mains frequency	[Hz]	50/60		
Operating pressure	[bar]	6		
Length	[mm]	1200		1760
Width	[mm]	1200		1360
Height	[mm]	875-1275		760-910 (without height adjustment) 800-1150 (with height adjustment)
Weight	[kg]	225		275

23.2 Requirements for fault-free operation


Compressed air quality must conform to ISO 8573-1: 2010 [7:4:4].






















DIN
A3





DÜRKOPP ADLER GmbH
Potsdamer Str. 190
33719 Bielefeld
Germany
Phone: +49 (0) 521 925 00
Email: service@duerkopp-adler.com
www.duerkopp-adler.com